







Cold Chain Equipment spare parts

Identification Guide

**Prepared by National Cold Chain Resource
Centre, Pune**

Sr. No.	EQUIPMENT TYPE	SPARE OF	GENERIC NAME	SPECIFIC NAME	PART NO	CODE NO	IMAGE
1	ILR/FREEZER	ELECTROLUX TCW-1151	STARTING DEVICE	STARTING DEVICE DANFOSS 117U6015	2912087-05/9	0001	
2	ILR/FREEZER	ELECTROLUX TCW-1151	COMPRESSOR	COMPRESSOR FR 8.5B	2100251-10/3	0002	
3	ILR/FREEZER	ELECTROLUX TCW-1151	CAPACITOR	CAPACITOR DANFOSS 117U5021	2912146-00/4	0003	
4	ILR/FREEZER	ELECTROLUX TCW-1151	FAN MOTOR	FAN MOTOR	2912073-00/0	0004	
5	ILR/FREEZER	ELECTROLUX TCW-1151	THERMOSTAT	THERMOSTAT REFRIGERATOR (007B0030)	2912478-01/1B	0005	
6	ILR/FREEZER	ELECTROLUX TCW-1151	THERMOSTAT	THERMOSTAT FREEZER, 007B2006	2912477-00/3	0006	

7	ILR/FREEZER	ELECTROLUX TCW-1151	THERMOSTAT KNOB	THERMOSTAT KNOBS	2911977- 00/3B	0007	
8	ILR/FREEZER	ELECTROLUX TCW-1151	TERMINAL COVER	TERMINAL COVER OF COMPRESSOR	210017-00/9	0008	
9	ILR/FREEZER	ELECTROLUX TCW-1151	THERMOMETER	THERMOMETER	2912559- 01/6B	0009	
10	ILR/FREEZER	ELECTROLUX TCW-1151	CLAMP	CLAMP	2910715-02/4	0010	
11	ILR/FREEZER	ELECTROLUX TCW-1151	TERMINAL CLIPS	TERMINAL CLIPS		0011	
12	ILR/FREEZER	ELECTROLUX TCW-1151	NUT	THERMOSTAT NUT		0012	
13	ILR/FREEZER	ELECTROLUX TCW-1151	GROMMET	GROMMET	2911979-00/9	0013	

14	ILR/FREEZER	ELECTROLUX TCW-1151	FAN BLADE	FAN (BLADES ONLY)	2911273-01/5	0014	
15	ILR/FREEZER	ELECTROLUX TCW-1151	LOCK	LOCK COMPLETE	2910565-03/1B	0015	
16	ILR/FREEZER	ELECTROLUX TCW-1151	KEY	KEY (FOR LOCK)		0016	
17	ILR/FREEZER	ELECTROLUX TCW-1151	INDICATOR LAMP	PILOT LAMP, YELLOW	291060-00/6B	0019	
18	ILR/FREEZER	ELECTROLUX TCW-1151	PANEL	THERMOSTAT PANEL WITHOUT TEXT	2911963-07/8B	0020	
19	ILR/FREEZER	ELECTROLUX TCW-1151	INDICATOR LAMP	PILOT LAMP, RED	2912373-00/4B	0021	
20	ILR/FREEZER	ELECTROLUX TCW-1151	HINGE	HINGE COMPLETE	2912574-02/3B	0022	

21	ILR/FREEZER	ELECTROLUX TCW-1151	HINGE PROTECTION	HINGE PROTECTION	2911639- 00/9B	0023	
22	ILR/FREEZER	ELECTROLUX TCW-1151	BUSHING	LOCK BUSHING	2910532- 00/7B	0024	
23	ILR/FREEZER	ELECTROLUX TCW-1151	PLUG	PLUG	2910548- 06/0B	0025	
24	ILR/FREEZER	ELECTROLUX TCW-1151	TUBE	TUBE, LONG	2911815- 01/3B	0027	
25	ILR/FREEZER	ELECTROLUX TCW-1151	TUBE	TUBE, SHORT	2911815- 02/1B	0028	
26	ILR/FREEZER	ELECTROLUX TCW-1151	FRAME	FRAME FOR THERMO- METER	2912558-00- 0B	0031	
27	ILR/FREEZER	ELECTROLUX TCW-1151	RETAINER	RETAINER FOR THERMO- METER	2910715- 03/2B	0032	








28	ILR/FREEZER	ELECTROLUX TCW-1151	CAP	CAP	2912234- 01/6B	0033	
29	ILR/FREEZER	ELECTROLUX TCW-1151	WASHER	WASHER 06.7 PL		0035	
30	ILR/FREEZER	ELECTROLUX TCW-1151	SCREW	SCREW M65 6X25	7252372- 50/8B	0036	
31	ILR/FREEZER	ELECTROLUX TCW-1151	DRIER	DRIER	2000298-06/3	0037	
32	ILR/FREEZER	ELECTROLUX TCW-1151	WASHER	LOCKING WASHER 4.1 MM		0038	
33	ILR/FREEZER	ELECTROLUX TCW-1151	NUT	DOOMED CAP NUT		0039	
34	ILR/FREEZER	ELECTROLUX TCW-1151	TERMINAL BLOCK	TERMINAL BLOCK	2911111-01/7	0040	








35	ILR/FREEZER	ELECTROLUX TCW-1151	SWITCH	SWITCH	2912372-00/6	0041	
36	ILR/FREEZER	ELECTROLUX TCW-1151	RETAINER	RETAINER THERMOSTAT FEELER	162539- 02/7B	0042	
37	ILR/FREEZER	ELECTROLUX TCW-1151	CAPILLARY	CAPILLARY TUBE		0044	
38	WALK - IN - COOLER	(HUU) WIC COOLING UNIT	COMPRESSOR	COMPRESSOR L,UNITE (TAJ 4511A)	309-10511	0045	
39	WALK - IN - COOLER	(HUU) WIC COOLING UNIT	COMPRESSOR	COMPRESSOR (AR 49) ASPERA (J6626M)	303- 11226	0046	
40	WALK - IN - COOLER	(HUU) WIC COOLING UNIT	FAN MOTOR	EVAPORATOR/CONDENS ER FAN MOTOR (AP 42)	101-11305	0047	
41	WALK - IN - COOLER	(HUU) WIC COOLING UNIT	CAPACITOR	EVAPORATOR/CONDENS ER FAN CAPACITOR (AM60)	101-79793	0048	








42	WALK - IN - COOLER	(HUU) WIC COOLING UNIT	TIMER	DEFROST TIMER (AV94) OLIGRAND-49823	142-54885	0049	
43	WALK - IN - COOLER	(HUU) WIC COOLING UNIT	VARISTERS	VARISTERS (R7) G.E METAL OXIDE VARISTER		0050	
44	WALK - IN - COOLER	(HUU) WIC COOLING UNIT	THERMOSTAT	THERMOSTAT (BA98) (ALSO IN ALARM HUU)		0051	
45	WALK - IN - COOLER	(HUU) WIC COOLING UNIT	PRESSOSTAT	PRESSOSTAT (COMPR) AM58 HP/LP, SAGI-DNS- D306X	112-56600	0052	
46	WALK - IN - COOLER	(HUU) WIC COOLING UNIT	PRESSOSTAT	PRESSOSTAT (CONDENSER FAN) HP (BA49) KP-5	112-56584	0053	
47	WALK - IN - COOLER	(HUU) WIC COOLING UNIT	CIRCUIT BREAKER	CIRCUIT BREAKER	130-41909	0054	
48	WALK - IN - COOLER	(HUU) WIC COOLING UNIT	INDICATOR LAMP	INDICATOR LAMPS GREEN	129-45059	0055	







49	WALK - IN - COOLER	(HUU) WIC COOLING UNIT	INDICATOR LAMP	INDICATOR LAMPS YELLOW	129-45069	0056	
50	WALK - IN - COOLER	(HUU) WIC COOLING UNIT	CONTACTOR	CONTACTOR (K1)	122-36450	0057	
51	WALK - IN - COOLER	(HUU) WIC ALARM SYSTEM	ALARM SYSTEM	ALARM SYSTEM (AH60) (COMPLETE UNIT)	141-10400	0058	
52	WALK - IN - COOLER	(HUU) WIC ALARM SYSTEM	ALARM DEVICE	ALARM DEVICE (A11) REMOTE SOUNDER	141- 10433	0059	
53	WALK - IN - COOLER	(HUU) WIC ALARM SYSTEM	RELAY	ALARM RELAY (K1)		0060	
54	WALK - IN - COOLER	(HUU) WIC ALARM SYSTEM	RELAY	ALARM RELAY (K2)		0061	
55	WALK - IN - COOLER	(HUU) WIC ALARM SYSTEM	TIMER	DELAY TIMER (R1) 0-60 Min	142-29810	0062	

56	WALK - IN - COOLER	(HUU) WIC GENR B & S PETROL ENGINE	FILTER	AIR FILTER CARTRIDGE B & S ENGINE	BS 390930	0063	
57	WALK - IN - COOLER	(HUU) WIC ALARM SYSTEM	SWITCH	MAIN SWITCH FOR ALARM CENTRE		0064	
58	WALK - IN - COOLER	(HUU) WIC ALARM SYSTEM	BUTTON	TEST BUTTON		0065	
59	WALK - IN - COOLER	(HUU) WIC ALARM SYSTEM	INDICATOR LAMP	INDICATOR LAMPS		0066	
60	WALK - IN - COOLER	(HUU) WIC HONDA PETROL ENGINE	SOLENOID	STARTING SOLENOID HONDA MDL G400		0067	
61	WALK - IN - COOLER	(HUU) WIC HONDA PETROL ENGINE	SOLENOID	AUTOMATIC CHOKE UNIT (SOLENOID) HONDA G400		0068	
62	WALK - IN - COOLER	(HUU) WIC B & S PETROL ENGINE	SPARK PLUG	SPARK PLUG B & S ENGINE	BS CJ-8	0069	

63	WALK - IN - COOLER	(HUU) WIC B & S PETROL ENGINE	FILTER	AIR FILTER SPONGE B & S ENGINE	BS 270782	0070	
64	WALK - IN - COOLER	(HUU) WIC B & S PETROL ENGINE	FILTER	FUEL FILTER B & S ENGINE	BS 394358	0071	
65	WALK - IN - COOLER	(HUU) WIC B & S PETROL ENGINE	OIL SEAL	OIL SEAL B & S ENGINE	BS 291675	0072	
66	WALK - IN - COOLER	(HUU) WIC B & S PETROL ENGINE	GASKET SET	GASKET SET B & S ENGINE	BS 391834	0073	
67	WALK - IN - COOLER	(HUU) WIC HONDA PETROL ENGINE	FILTER	AIR FILTER ELEMENT HONDA ENGINE	H 17211-890-023	0074	
68	WALK - IN - COOLER	(HUU) WIC HONDA PETROL ENGINE	CARBON	CARBONS FOR STARTER HONDA ENGINE	H 31215-890-801	0075	
69	WALK - IN - COOLER	(HUU) WIC HONDA PETROL ENGINE	SPARK PLUG	SPARK PLUGS-HONDA ENGINE – HW14FPR – UL 10	98076-54954	0076	

70	WALK - IN - COOLER	(HUU) WIC HONDA PETROL ENGINE	GASKET SET	GASKET SET FOR CARBURETOR HONDA ENGINE	H 16010-883-005	0077	
71	WALK - IN - COOLER	(HUU) WIC HONDA PETROL ENGINE	GASKET SET	GASKET SET HONDA ENGINE	H O61A1-890-020	0078	
72	WALK - IN - COOLER	(HUU) WIC HONDA PETROL ENGINE	CARBURETOR	CARBURETOR HONDA ENGINE		0079	
73	WALK - IN - COOLER	(HUU) WIC MECC ALTE ALTERNATOR	MOUNTING SET	MOUNTING SET (6) FOR GENERATOR MECC ALTE	GPA 3	0080	
74	WALK - IN - COOLER	(HUU) WIC HONDA PETROL ENGINE	FAN BLADE	FAN BLADES HONDA G400	GPA 3	0081	
75	WALK - IN - COOLER	(HUU) WIC MECC ALTE ALTERNATOR	DIODE	DIODE FOR ROTARY BRIDGE MECC ALTE		0082	
76	WALK - IN - COOLER	(HUU) WIC MECC ALTE ALTERNATOR	RECTIFIER	RECTIFYING BRIDGE MECC ALTE	391400601	0083	

77	WALK - IN - COOLER	(HUU) WIC MECC ALTE ALTERNATOR	TRANSFORMER	REGULATOR TRANSFORMER MECC ALTE GTA 3T /2		0084	
78	WALK - IN - COOLER	(HUU) WIC MECC MISC SPARE	TEMPERATURE RECORDER	TEMPERATURE RECORDER UNIT ELMES, A31108		0085	
79	WALK - IN - COOLER	(HUU) WIC MECC MISC SPARE	SENSOR	SENSOR BULB A32698		0086	
80	WALK - IN - COOLER	(HUU) WIC MECC MISC SPARE	BATTERY	BATTERY 3.4V SIZE AA HI ENGY LITH TL - 2100		0087	
81	WALK - IN - COOLER	(HUU) WIC MECC MISC SPARE	CHART	RECORDING CHARTS PKT -30°C-0-+20°C/7 DAY	100 PC PKT	0088	
82	WALK - IN - COOLER	(HUU) WIC GENR PANEL	DOOR GASKET	DOOR GASKET		0089	
83	WALK - IN - COOLER	(HUU) WIC GENR PANEL	CIRCUIT BREAKER	CIRCUIT BKRS 10A	410-45425	0090	

84	WALK - IN - COOLER	(HUU) WIC GENR PANEL	CIRCUIT BREAKER	CIRCUIT BKRS 16A		0091	
85	WALK - IN - COOLER	(HUU) WIC GENR PANEL	TRANSFORMER	TRANSFORMER SUPPLY (FBI) 220/3.4 V		0092	
86	WALK - IN - COOLER	(HUU) WIC GENR PANEL	CONTACTOR	CONTACTOR (K1) NETWK ,DANFOSS C125-25A	HR 10025	0093	
87	WALK - IN - COOLER	(HUU) WIC GENR PANEL	CONTACTOR	CONTACTOR (K2) ,GENR, DANFOSS C1 16	HR 10016	0094	
88	WALK - IN - COOLER	(HUU) WIC GENR PANEL	RELAY	SEQUENCE RELAY (K11/21) SM 170 380	HR 100170	0095	
89	WALK - IN - COOLER	(HUU) WIC GENR PANEL	RELAY	TIME DELAY RELAY (K12/22) SA 205 220	HR 100205	0096	
90	WALK - IN - COOLER	(HUU) WIC GENR PANEL	RELAY	RELAY K13 ELESTA SKR - 115, 50/60 HZ	HR 100K13	0097	

91	WALK - IN - COOLER	(HUU) WIC GENR PANEL	RELAY	RELAY K23 (DRIVEMAN) SCHARK, RL 301012	HR 100K23	0098	
92	WALK - IN - COOLER	(HUU) WIC GENR PANEL	PRINTED CIRCUIT BOARD	KAP 3 CKT-CARD GENR. CONTROL	HR 100 KAP3	0099	
93	WALK - IN - COOLER	(HUU) WIC GENR PANEL	PRINTED CIRCUIT BOARD	KAP 4 CKT-CARD 3.4 VOLT RECTIFIER	HR 100 KAP4	0100	
94	WALK - IN - COOLER	(HUU) WIC GENR PANEL	SWITCH	MAIN SWITCH (S1)		0101	
95	WALK - IN - COOLER	(HUU) WIC GENR PANEL	SWITCH	SELECTOR (S11)		0102	
96	WALK - IN - COOLER	(HUU) WIC GENR PANEL	BUTTON	PRESS BUTTON (START/STOP) NO		0103	
97	WALK - IN - COOLER	(HUU) WIC GENR PANEL	BUTTON	PRESS BUTTON (RESET) NC		0104	

98	WALK - IN - COOLER	(HUU) WIC GENR PANEL	SWITCH	SELECTOR SWITCH HAND/AUTO (S15)		0105	
99	WALK - IN - COOLER	(HUU) WIC GENR PANEL	CONNECTOR	TERMINAL CONNS. STRIP FOR KAP 3 (XA & XB)		0107	
100	WALK - IN - COOLER	(HUU) WIC GENR PANEL	INDICATOR LAMPS	INDICATOR LAMPS (H1 & H2)		0108	
101	WALK - IN - COOLER	(HUU) WIC GENR PANEL	VARISTER	VARISTER Y227A3 OR V33725 OR PILLO: 593 (AX33)		0109	
102	WALK-IN-COOLER	(FOS) WIC COOLING UNIT	FAN MOTOR	FAN MOTOR (UE) X 200/250V	15870002	0110	
103	WALK-IN-COOLER	(FOS) WIC COOLING UNIT	FAN MOTOR	FAN MOTOR GEC/VE 200/250V	158700021	0111	
104	WALK-IN-COOLER	(FOS) WIC COOLING UNIT	CAPACITOR	MOTOR CAPACITOR (FAN) 2 MFD + / - 5% 450V 50Hz		0112	








105	WALK-IN-COOLER	(FOS) WIC COOLING UNIT	FAN BLADE	FAN BLADE 10" DIA SOLAR	15871021/29	0113	
106	WALK-IN-COOLER	(FOS) WIC COOLING UNIT	GUARD	FAN GUARD 10 1/2" DIA SOLAR	15872021	0114	
107	WALK-IN-COOLER	(FOS) WIC COOLING UNIT	COMPRESSOR	COMPRESSOR CAJ4511	15422121	0115	
108	WALK-IN-COOLER	(FOS) WIC COOLING UNIT	RELAY	RELAY GE 3ARR3 A3 AV3		0116	
109	WALK-IN-COOLER	(FOS) WIC COOLING UNIT	OVER LOAD PROTECTOR	OVERLOAD PROTECTOR MRT 16AHKE 3021	15490154	0117	
110	WALK-IN-COOLER	(FOS) WIC COOLING UNIT	CAPACITOR	START CAPACITOR 88 108 MFD	15490045	0118	
111	WALK-IN-COOLER	(FOS) WIC COOLING UNIT	CAPACITOR	RUN CAPACITOR 15 MFD	15490011	0119	

122	WALK-IN-COOLER	(FOS) WIC COOLING UNIT	DRIER	DRIER 3/8" FLARE/DANFOSS	15480903	0120	
113	WALK-IN-COOLER	(FOS) WIC COOLING UNIT	SIGHT GLASS	SIGHT GLASS 3/8" FLARE	15483002	0121	
114	WALK-IN-COOLER	(FOS) WIC COOLING UNIT	VALVE	EXPANSION VALVE TF2-1.0 DANFOSS	15450007	0122	
115	WALK-IN-COOLER	(FOS) WIC COOLING UNIT	THERMOSTAT	THERMOSTAT RANCO/016-6954	15452104	0123	
116	WALK-IN-COOLER	(FOS) WIC COOLING UNIT	SWITCH	ON/OFF SWITCH	1541802	0124	
117	WALK-IN-COOLER	(FOS) WIC COOLING UNIT	THERMOMETER	THERMOMETER TODDINGTON	15850012	0125	
118	WALK-IN-COOLER	(FOS) WIC COOLING UNIT	INDICATOR LAMP	MAINS INDICATOR LAMP GREEN	154841600	0126	

119	WALK-IN-COOLER	(FOS) WIC COOLING UNIT	INDICATOR LAMP	REFR. INDICATOR LAMP WHITE	15941602	0127	
120	WALK-IN-COOLER	(FOS) WIC COOLING UNIT	LIQUID RECEIVER	LIQUID RECEIVER VLR 90/40		0128	
121	WALK-IN-COOLER	(FOS) WIC COOLING UNIT	PRESSOSTAT	HIGH/LOW PRESSURE SWITCH RANCO/DANF-KP15 H.6701.01	15852000	0129	
122	WALK-IN-COOLER	(FOS) WIC COOLING UNIT	CIRCUIT BREAKER	CIRCUIT BREAKER	15841908	0130	
123	WALK-IN-COOLER	(FOS) WIC COOLING UNIT	CIRCUIT BREAKER	CIRCUIT BREAKER	15841900	0131	
124	WALK-IN-COOLER	(FOS) WIC COOLING UNIT	CONTACTOR	CONTACTOR	15841102	0132	
125	WALK-IN-COOLER	(FOS) WIC COOLING UNIT	CAPILLARY	CAPILLARY PIPE		0133	

126	WALK-IN-COOLER	(FOS) WIC COOLING UNIT	EVAPORATOR	EVAPORATOR UNIT		0134	
127	WALK-IN-COOLER	(FOS) WIC COOLING UNIT	CONDENSER UNIT	CONDENSER UNIT		0135	
128	WALK-IN-COOLER	(FOS) WIC COOLING UNIT	FAN MOTOR	EVAPORATOR FANS COMPLETE		0136	
129	WALK-IN-COOLER	(FOS) WIC COOLING UNIT	PANEL	CONTROL PANEL COMPLETE 1ph		0137	
130	WALK-IN-COOLER	(FOS) WIC COLD ROOM	DOOR HEATER	DOOR HEATER ASSEMBLY		0138	
131	WALK-IN-COOLER	(FOS) WIC COLD ROOM	LIGHT	ROOM LIGHT SWITCH		0139	
132	WALK-IN-COOLER	(FOS) WIC COLD ROOM	RELAY	CHANGE OVER RELAY (C3/C4) OLD (= 0165)	EN 305 220	0140	

133	WALK-IN-COOLER	(FOS) WIC COLD ROOM	RELAY	ALARM RELAY 0-60 Min (D1) OLD TYPE PANEL		0141	
135	WALK-IN-COOLER	(FOS) WIC COLD ROOM	INDICATOR LAMPS	INDICATOR LAMPS		0142	
136	WALK-IN-COOLER	(FOS) WIC COLD ROOM	THERMOSTAT	ALARM THERMOSTAT (T1)		0143	
137	WALK-IN-COOLER	(FOS) WIC COLD ROOM	BUTTON	RESET BUTTON (ALARM) (B2)		0144	
138	WALK-IN-COOLER	(FOS) WIC COLD ROOM	SWITCH	SELECTOR SWITCH (2 WAY) (B3)		0145	
139	WALK-IN-COOLER	(FOS) WIC COLD ROOM	CIRCUIT BREAKER	CIRCUIT BREAKER (16 A) 2 WAY		0146	
140	WALK-IN-COOLER	(FOS) WIC COLD ROOM	RELAY	ALARM RELAY (TIMER) (C1) NEW TYPE PANEL		0147	





141	WALK-IN-COOLER	(FOS) WIC COLD ROOM	RELAY	LOW VOLTAGE PROTECTOR SM 125 (CL) NEW		0148	
142	WALK-IN-COOLER	(FOS) WIC COLD ROOM	FIBRE PEN CAPSULE	FIBRE PEN CAPSULES CAMBRIDGE T/RECORDER		0149	
143	WALK-IN-COOLER	(FOS) WIC COLD ROOM	THERMOSTAT	KP 73 THERMOSTAT		0151	
144	WALK-IN-COOLER	(FOS) WIC COLD ROOM	RELAY	RELAY (SCHRACK)		0152	
145	WALK-IN-COOLER	(FOS) WIC COLD ROOM	GASKET SET	DOOR GASKET		0153	
146	WALK-IN-COOLER/FREEZER	(FOS) WIC/F MISC SPARE	TEMPERATURE RECORDER	TEMPERATURE RECORDER UNIT CAMBRIDGE C105		0154	
147	WALK-IN-COOLER/FREEZER	(FOS) WIC/F MISC SPARE	CHART	RECORDER CHARTS FOR CAMBRIDGE T/R	1302	0155	

148	WALK-IN-COOLER	(FOS) WIC GENR PANEL	CONTACTOR	MAIN CONTACTOR (NK) BBC. 25-30-10	6960-22-04	0156	
149	WALK-IN-COOLER	(FOS) WIC GENR PANEL	AUXILIARY CONTACT BLOCK	AUX. BLOCK FOR NK (NO) BBC CA -7-01		0157	
150	WALK-IN-COOLER	(FOS) WIC GENR PANEL	METER	VOLTMETER	6960-22-06	0158	
151	WALK-IN-COOLER	(FOS) WIC GENR PANEL	METER	AMPERE METER	6960-22-06	0159	
152	WALK-IN-COOLER	(FOS) WIC GENR PANEL	CONTACTOR	ALTERNATOR CONTACTOR (GK) BBC 25-30-10	6960-22-02	0160	
153	WALK-IN-COOLER	(FOS) WIC GENR PANEL	AUXILIARY CONTACT BLOCK	AUX. BLOCK FOR GK BBC CA-7-10	6960-22-03	0161	
154	WALK-IN-COOLER	(FOS) WIC GENR PANEL	CIRCUIT BREAKER	MINI CKT BREAKER 1 PH	6960-22-01	0162	





155	WALK-IN-COOLER/FREEZER	(FOS) WIC/F GENR PANEL	TIMER	TIMER 3 ATTEMPT 0-12 SEC		0163	
156	WALK-IN-COOLER/FREEZER	(FOS) WIC/F GENR PANEL	RELAY	SA 245 RELAY		0164	
157	WALK-IN-COOLER/FREEZER	(FOS) WIC/F GENR PANEL	RELAY	EN 305 RELAY (N1) (SAME AS 0140)	EN 305 220	0165	
158	WALK-IN-FREEZER	(FOS) WIF GENR PANEL	CONTACTOR	MAIN CONTACTOR (NK) 3 PH	6960-40-05	0166	
159	WALK-IN-FREEZER	(FOS) WIF GENR PANEL	AUXILIARY CONTACT BLOCK	AUX BLOCK FOR NK 3 PH	6960-40-04	0167	
160	WALK-IN-FREEZER	(FOS) WIF GENR PANEL	METER	VOLTMETER	6960-40-06	0168	
161	WALK-IN-FREEZER	(FOS) WIF GENR PANEL	METER	AMPERE METER	6960-40-07	0169	





162	WALK-IN-FREEZER	(FOS) WIF GENR PANEL	CONTACTOR	ALTERNATOR CONTACTOR (GK) 3 PH	6960-40-02	0170	
163	WALK-IN-FREEZER	(FOS) WIF GENR PANEL	AUXILIARY CONTACT BLOCK	AUX. BLOCK FOR GK	6960-40-03	0171	
164	WALK-IN-FREEZER	(FOS) WIF GENR PANEL	CIRCUIT BREAKER	MINI CIRCUIT BREAKER 3 PH	6960-40-01	0172	
165	WALK-IN-FREEZER	(FOS) WIF GENR PANEL	RELAY	RELAY N2/N3	6960-40-20	0173	
166	WALK-IN-FREEZER	(FOS) WIF GENR PANEL	PANEL	COMPLETE CONTROL BOX 3 PH		0174	
167	WALK-IN-FREEZER	(FOS) WIF COOLING UNIT	CONTACTOR	DEFROST CONTACTOR (C2)		0175	
168	WALK-IN-FREEZER	(FOS) WIF COOLING UNIT	HEATER	AIR VENT HEATER ASSY		0176	

169	WALK-IN-FREEZER	(FOS) WIF COOLING UNIT	COMPRESSOR UNIT	COMPRESSOR UNIT 3-PHASE	15422121	0177	
170	WALK-IN-FREEZER	(FOS) WIF COOLING UNIT	VALVE	SOLENOID VALVE FOR UNIT	15451213	0178	
171	WALK-IN-FREEZER	(FOS) WIF COOLING UNIT	HEATER	DEFROST HEATERS	1584361	0179	
172	WALK-IN-FREEZER	(FOS) WIF COOLING UNIT	CONTACTOR	CONTACTORS C1 AND C2 ROOM PANEL		0181	
173	WALK-IN-FREEZER	(FOS) WIF COOLING UNIT	FUSE	AUTOMATIC FUSE 3 PH		0182	
174	WALK-IN-FREEZER	(FOS) WIF COOLING UNIT	OVER LOAD PROTECTOR	COMP.ALARM BOX	15841921	0183	
175	WALK-IN-FREEZER	(FOS) WIF COOLING UNIT	PIPE	FLEXIBLE PIPE 3/4		0185	

176	WALK-IN-FREEZER	(FOS) WIF COOLING UNIT	REFRIGERANT	R502 Kg		0186	
177	WALK-IN-FREEZER	(FOS) WIF COOLING UNIT	EVAPORATOR	EVAPORATOR		0188	
178	WALK-IN-FREEZER	(FOS) WIF COOLING UNIT	VALVE	EXPANSION VALVE		0189	
179	WALK-IN-FREEZER	(FOS) WIF COOLING UNIT	FILTER	BURNOUT FILTER AL-30-75C		0191	
180	WALK-IN-FREEZER	(FOS) WIF COLD ROOM	SWITCH	PRESSURE RELEASE SWITCH		0192	
181	WALK-IN-FREEZER	(FOS) WIF COLD ROOM	HANDLE	DOOR HANDLE		0193	
182	WALK-IN-FREEZER	(FOS) WIF COLD ROOM	HINGE	DOOR HINGES SET		0194	








183	WALK-IN-FREEZER	(FOS) WIF COLD ROOM	FUSE	AUTOMATIC FUSE B1 NEW		0195	
184	WALK-IN COOLER/FREEZER	(FOS) WIC/F GENR PANEL	HOLDER	FUSE HOLDERS	6960-22-07	0196	
185	WALK-IN COOLER/FREEZER	(FOS) WIC/F GENR PANEL	FUSE	FUSE 5A	6960-22-08	0197	
186	WALK-IN COOLER/FREEZER	(FOS) WIC/F GENR PANEL	FUSE	FUSE 8A	6960-22-09	0198	
187	WALK-IN COOLER/FREEZER	(FOS) WIC/F GENR PANEL	SWITCH	SELECTOR SWITCH A1	6960-22-10	0199	
188	WALK-IN COOLER/FREEZER	(FOS) WIC/F GENR PANEL	BUTTON	PUSH BUTTON ASSY NO RED	6960-22-11	0200	
189	WALK-IN COOLER/FREEZER	(FOS) WIC/F GENR PANEL	BUTTON	PUSH BUTTON ASSY NO GREEN	6960-22-12	0201	

190		(FOS) WIC/F GENR PANEL	INDICATOR LAMPS	INDICATOR LAMP 12V	6960-22-13	0202	
191		(FOS) WIC/F GENR PANEL	INDICATOR LAMPS	INDICATOR LAMP 220V	6960-22-14	0203	
192	WALK-IN COOLER/FRE EZER	(FOS) WIC/F GENR PANEL	TIMER	TIMER, 0 – 60S START (FI)	6960-22-15	0204	
193	WALK-IN COOLER/FRE EZER	(FOS) WIC/F GENR PANEL	TIMER	TIMER, 0 – 60S STOP (FU)	6960-22-16	0205	
194	WALK-IN COOLER/FRE EZER	(FOS) WIC/F GENR PANEL	TIMER	TIMER, 0 – 60S T3	6960-22-17	0206	
195	WALK-IN COOLER/FRE EZER	(FOS) WIC/F GENR PANEL	RELAY	RELAY R1	6960-22-18	0207	
196	WALK-IN COOLER/FRE EZER	(FOS) WIC/F GENR PANEL	RELAY	RELAY R2	6960-22-19	0208	

197	WALK-IN COOLER/FREEZER	(FOS) WIC/F GENR PANEL	REGULATOR	ALTERNATOR REGULATOR LC 24 C		0209	
198	WALK-IN COOLER/FREEZER	(FOS) WIC/F GENR PANEL	RELAY	12/20 A RELAY BOSCH START AND STOP RH1&RH2	6960-22-21	0210	
199	WALK-IN COOLER/FREEZER	(FOS) WIC/F GENR PANEL	RECTIFIER	AUTOMATIC CHARGING RECTIFIER UNIT	6960-22-22	0211	
200	WALK-IN COOLER/FREEZER	(FOS) WIC/F GENR PANEL	RECTIFIER	RECTIFIER D1, 2,3= 1A	6960-22-23	0212	
201		(FOS) WIC/F DIESEL ENGINE DM188	INJECTOR	INJECTOR DM 188		0213	
202	WALK-IN COOLER/FREEZER	(FOS) WIC/F DIESEL ENGINE DM188	PUMP	INJECTOR PUMP DM 188		0214	
203	WALK-IN COOLER/FREEZER	(FOS) WIC/F DIESEL ENGINE DM188	DEARACTOR	DEARACTOR DM 188		0215	








204	WALK-IN COOLER/FREZER	(FOS) WIC/F DIESEL ENGINE DM188	PIPE	FUEL FEED PIPE DM 188		0216	
205	WALK-IN COOLER/FREZER	(FOS) WIC/F DIESEL ENGINE DM188	PIPE	DELIVERY PIPE TO INJECTOR DM 188		0217	
206	WALK-IN COOLER/FREZER	(FOS) WIC/F DIESEL ENGINE DM188	DEARACTOR	INJECTOR WASTE/DEARACTOR BACK FLOW PIPE		0218	
207	WALK-IN COOLER/FREZER	(FOS) WIC/F DIESEL ENGINE DM188	FILTER	FUEL FILTER ELEMENTS DM 188		0219	
208	WALK-IN COOLER/FREZER	(FOS) WIC/F DIESEL ENGINE DM188	VALVE	BLEEDING VALVE DM 188		0220	
209	WALK-IN COOLER/FREZER	(FOS) WIC/F DIESEL ENGINE DM188	FILTER	FEED PUMP FILTER ELEMENTS DM 188		0221	
210	WALK-IN COOLER/FREZER	(FOS) WIC/F DIESEL ENGINE DM188	FILTER	AIR FILTER COMPLETE DM 188		0222	

211	WALK-IN COOLER/FRE EZER	(FOS) WIC/F DIESEL ENGINE DM188	FILTER	OIL FILTER ELEMENT DM 188		0223	
212	WALK-IN COOLER/FRE EZER	(FOS) WIC/F DIESEL ENGINE DM188	SWITCH	OIL PRESSURE SWITCH PRESOSTAT DM 188		0224	
213	WALK-IN COOLER/FRE EZER	(FOS) WIC/F DIESEL ENGINE DM188	THERMOSTAT	THERMOSTAT DM 188 TEMPERATURE SWITCH		0225	
214	WALK-IN COOLER/FRE EZER	(FOS) WIC/F DIESEL ENGINE DM188	PIPE	FLEXIBLE PIPE TO PRESSURE GAUGE		0226	
215	WALK-IN COOLER/FRE EZER	(FOS) WIC/F DIESEL ENGINE DM188	GEAR	FLYWHEEL RING GEAR DM 188/SIEPRA 8736	175-182-188	0227	
216	WALK-IN COOLER/FRE EZER	(FOS) WIC/F DIESEL ENGINE DM188	SOLENOID	START MOTOR SOLENOID DM 188	35532007A	0228	
217	WALK-IN COOLER/FRE EZER	(FOS) WIC/F DIESEL ENGINE DM188	RELAY	CHARGING RELAY DM 188 DUCATI ENERGIA	8609(343501)	0229	



218	WALK-IN COOLER/FREEZER	(FOS) WIC/F DIESEL ENGINE DM188	SOLENOID	STOP SOLENOID ASSY DM 188 BOSCH	331402077	0230	
219	WALK-IN COOLER/FREEZER	(FOS) WIC/F DIESEL ENGINE DM188	STARTER MOTOR	STARTER MOTOR DM 188		0231	
220	WALK-IN COOLER/FREEZER	(FOS) WIC/F DIESEL ENGINE DM188	DYNAMO	DYNAMO (CHARGING ALTERNATOR) DM 188		0232	
221	WALK-IN COOLER/FREEZER	(FOS) WIC/F DIESEL ENGINE DM188	CAPACITOR	STARTING CAPR		0233	
222	WALK-IN COOLER/FREEZER	(FOS) WIC/F GEN - ALTER	BRUSH	BRUSH AC		0234	
223	WALK-IN COOLER/FREEZER	(FOS) WIC/F GEN - ALTER	BRUSH	BRUSH DC		0235	
224	WALK-IN COOLER/FREEZER	(FOS) WIC/F GEN - ALTER	BEARING	BEARING NDE		0236	


225	WALK-IN COOLER/FREEZER	(FOS) WIC/F GEN - ALTER	BEARING	BEARING DE		0237	
226	WALK-IN-FREEZER	(FOS) WIF GEN -ALTER	RECTIFIER	RECTIFIER DIODE 3 ph FORWARD POLARITY		0238	
227	WALK-IN-COOLER	(FOS) WIC GEN -ALTER	RECTIFIER	RECTIFIER DIODE 1 ph FORWARD POLARITY		0239	
228	WALK-IN-FREEZER	(FOS) WIF GEN -ALTER	RECTIFIER	RECTIFIER DIODE 3 ph REVERSE POLARITY		0240	
229	WALK-IN-COOLER	(FOS) WIC - GEN ALTER	RECTIFIER	RECTIFIER DIODE 1 ph REVERSE POLARITY		0241	
230	WALK-IN-COOLER/FREEZER	(FOS) WIC/F GEN -ALTER	HOLDER	BRUSH HOLDER		0242	
231	WALK-IN-COOLER/FREEZER	(FOS) WIC/F GEN- ALTER	BRUSH	BRUSH ARM COMPLETE		0243	





232	WALK - IN - COOLER	HUURRE WIC GENR PANEL	AUXILIARY CONTACT BLOCK	AUXILIARY CONTACTS FOR K1/K2, CB -NO (3-4)		0266	
233	WALK - IN - COOLER	HUU WIC WITH B & S PETROL ENGINE	AUXILIARY CONTACT BLOCK	AUXILIARY CONTACTS FOR K1/K2, CB-NC (1-2)		0267	
234	WALK - IN - COOLER	(HUU) WIC MISC SPARE	LIGHT	BULB FOR ROOM LIGHT 60 W 220V	129-12272	0268	
235	WALK - IN - COOLER	(HUU) WIC B & S PETROL ENGINE	STARTER MOTOR	STARTER UNIT COMPLETE B&S M.252417 TY.0526 11 HP		0269	
236	WALK - IN - COOLER	(HUU) WIC B & S PETROL ENGINE	GEAR	STARTER PINION (GEAR) B&S M.25417 TY.0526 11 HP		0270	
237	WALK - IN - COOLER	(HUU) WIC B & S PETROL ENGINE	PISTON	PISTON RING SET B&S M 25417 TY. 0526 11 HP		0271	
238	WALK - IN - COOLER	(HUU) WIC B & S PETROL ENGINE	VALVE	INLET VALVE B&S 25417 TY. 0526 11 HP		0272	







239	WALK - IN - COOLER	(HUU) WIC B & S PETROL ENGINE	VALVE	EXHAUST VALVE B&S M 25417 TY. 0526 11 HP		0273	
240	WALK - IN - COOLER	(HUU) WIC B & S PETROL ENGINE	CLUTCH	CLUTCH (COUPLING) B&S M 25417 TY. 0526 11 HP		0274	
241	WALK - IN - COOLER	(HUU) WIC B & S PETROL ENGINE	GEAR	FLYWHEEL RING GEAR B&S M 25417 TY. 0526 11 HP		0275	
242	WALK - IN - COOLER	(HUU) WIC B & S PETROL ENGINE	KEY	FLYWHEEL KEY B&S M 25417 TY. 0526 11 HP		0276	
243	WALK - IN - COOLER	(HUU) WIC B & S PETROL ENGINE	CARBURETOR	CARBURETOR KIT B&S M 25417 TY. 0526 11 HP		0277	
244	WALK - IN - COOLER	(HUU) WIC B & S PETROL ENGINE	MAGNETO	MAGNETO WEDGE B&S M 25417 TY. 0526 11 HP		0278	
245	WALK - IN - COOLER	(HUU) WIC B & S PETROL ENGINE	STARTER ROTOR	STARTER ROTOR B&S M 25417 TY. 0526 11 HP		0279	

246	WALK - IN - COOLER	(HUU) WIC B & S PETROL ENGINE	FILTER	FILTER DRY FLEX B&S M 25417 TY. 0526 11 HP		0280	
247	WALK - IN - COOLER	(HUU) WIC B & S PETROL ENGINE	CLEANER	FUEL CLEANER B&S M 25417 TY. 0526 11 HP		0281	
248	WALK - IN - COOLER	(HUU) WIC B & S PETROL ENGINE	IGNITION MODULE	IGNITION MODULE B&S M 25417 TY. 0526 11 HP	298968	0282	
249	WALK - IN - COOLER	(HUU) WIC HONDA PETROL ENGINE	RECTIFIER	DIODE RECTIFIER S3C-01 (6.5) HONDA MDL G400	31700-890-801	0283	
250	WALK - IN - COOLER	(HUU) WIC HONDA PETROL ENGINE	STARTER MOTOR	STARTER UNIT COMPLETE HONDA MDL G400	31200-980-802	0284	
251	WALK - IN - COOLER	(HUU) WIC HONDA PETROL ENGINE	CHARGER	CHARGING COIL HONDA MDL G400	31630-890-801	0285	
252	WALK - IN - COOLER	(HUU) WIC HONDA PETROL ENGINE	SWITCH	CONTACT BREAKER HONDA MDL G400	30280-890-000	0286	

253	WALK - IN - COOLER	(HUU) WIC HONDA PETROL ENGINE	VALVE	FUEL VALVE HONDA MDL G400	16950-898-631	0287	
254	WALK - IN - COOLER	(HUU) WIC HONDA PETROL ENGINE	VALVE	FLOAT VALVE HONDA MDL G400	16011-382-004	0288	
255	WALK - IN - COOLER	(HUU) WIC COOLING UNIT	SWITCH	ON/OFF SWITCH	127-10113	0291	
256	WALK-IN-COOLER	(FOS) WIC COOLING UNIT	TIMER	DEFROST TIMER SYB11622 FLASH	15452500	0293	
257	FOSTER WIC/F	(FOS) WIC/F GENR PANEL	CAPACITOR	CAPACITOR FOR T1 220MF		0295	
258	WALK-IN-COOLER/FREEZER	(FOS) WIC/F DIESEL ENGINE	SEAL	OIL SEAL (A)		0297	
259	WALK-IN-COOLER/FREEZER	(FOS) WIC COOLING UNIT	TIMER	DEFROST TIMER SYB11622 FLASH	15452500	0298	

260	WALK-IN-COOLER/FREEZER	(FOS) WIC/F DIESEL ENGINE	SEAL	OIL SEAL (B)		0299	
261	WALK-IN-COOLER/FREEZER	(FOS) WIC/F DIESEL ENGINE	BEARING	BEARING (A)		0300	
262	WALK-IN-COOLER/FREEZER	(FOS) WIC/F DIESEL ENGINE	BEARING	BEARING (B)		0301	
263	WALK-IN-COOLER/FREEZER	(FOS) WIC/F DIESEL ENGINE	BEARING	BEARING ©		0302	
264	WALK-IN-COOLER/FREEZER	(FOS) WIC/F DIESEL ENGINE	BEARING	BEARING (D)		0303	
265	WALK-IN-COOLER/FREEZER	(FOS) WIC/F DIESEL ENGINE	PISTON	PISTON ASSEMBLY		0304	
266	WALK-IN-COOLER/FREEZER	(FOS) WIC/F DIESEL ENGINE	RING SET	RING SET		0305	








267	WALK-IN-COOLER/FREEZER	(FOS) WIC/F DIESEL ENGINE	BEARING	THRUST BEARING		0306	
268	WALK-IN-COOLER/FREEZER	(FOS) WIC/F DIESEL ENGINE	PUMP	OIL PUMP		0307	
269	WALK-IN-COOLER/FREEZER	(FOS) WIC/F DIESEL ENGINE	VALVE	INLET VALVE		0311	
270	WALK-IN-COOLER/FREEZER	(FOS) WIC/F DIESEL ENGINE	VALVE	OUTLET VALVE		0312	
271	WALK-IN-COOLER/FREEZER	(FOS) WIC/F DIESEL ENGINE	NOZZLE	NOZZLE DM 188		0313	
272	WALK-IN-COOLER/FREEZER	(FOS) WIC/F DIESEL ENGINE	LINER	CYLINDER LINER		0317	
273	WALK-IN-COOLER/FREEZER	(FOS) WIC/F DIESEL ENGINE	CAP	OIL FILTER CAP		0318	

274	WALK-IN-COOLER/FREEZER	(FOS) WIC/F DIESEL ENGINE	GAUGE	MANOMETER COMPLETE (OIL PR. GAUGE)		0319	
275	WALK - IN - COOLER	(HUU) WIC B & S PETROL ENGINE	SWITCH	CONTACT BREAKER B&S M. 252417 TY: 0526	391284	0320	
276	WALK - IN - COOLER	(HUU) WIC B & S PETROL ENGINE	IGNITION SYS	CONDENSER (IGN.CKT) B&S M. 252417 TY: 0526	29861	0321	
277	WALK - IN - COOLER	(HUU) WIC HONDA PETROL ENGINE	IGNITION SYS	CONDENSER (IGN.CKT) HONDA MDL G400		0322	
278	WALK - IN - COOLER	(HUU) WIC HONDA PETROL ENGINE	IGNITION SYS	IGNITION MODULE HONDA MDL G400 (COMP)	30560-890-801	0323	
279	WALK - IN - COOLER	(HUU) WIC HONDA PETROL ENGINE	VALVE	INLET VALVE HONDA G-400	14711-890-000	0324	
280	WALK - IN - COOLER	(HUU) WIC HONDA PETROL ENGINE	VALVE	EXHAUST VALVE HONDA MDL G-400	14721-890-000	0325	








281	WALK - IN - COOLER	(HUU) WIC HONDA PETROL ENGINE	RING SET	PISTON RING SET HONDA MDL G-400	13010-890-010	0326	
282	WALK - IN - COOLER	(HUU) WIC HONDA PETROL ENGINE	SEAL	OIL SEAL 30X46X8	91201-890-003	0327	
283	WALK - IN - COOLER	(HUU) WIC HONDA PETROL ENGINE	SOLENOID	START SOLENOID B&S 082-EC 154-5		0328	
284	WALK - IN - COOLER	(HUU) WIC HONDA PETROL ENGINE	FAN BLADE	FAN BLADE MECALTE GTA 3T/2		0329	
285	WALK - IN - COOLER/FRE EZER	(HUD) WIC/F MISC SPARE	TEMPERATURE RECORDER	TEMP RECORDER COMPLETE UNIT (NEW)	BL-16	0330	
286	WALK - IN - COOLER/FRE EZER	(HUD) WIC/F MISC SPARE	CHART	TEMP RECORDING CHART 100 PCS (D31690)	BL-97	0331	
287	WALK - IN - COOLER/FRE EZER	(HUD) WIC/F MISC SPARE	FIBRE PEN CAPSULE	FIBRE PENS FOR TEMP RECORDER	BL-98	0332	

288	WALK - IN - FREEZER	(HUD) WIF ALARM SYS	ALARM SYSTEM	ALARM UNIT (COMPLETE)	AH-60	0333	
289	WALK - IN - FREEZER	(HUD) WIF ALARM SYS	BATTERY	BATTERY FOR ALARM UNIT	AT 75	0336	
290	WALK - IN - COOLER/FREEZER	(HUD) WIC/F GENR PANEL	CHARGER	TRICKLE CHARGING DEVICE FOR BATTERY	Defa-1202	0337	
291	WALK - IN - COOLER/FREEZER	(HUD) WIC/F GENR PANEL	CAPACITOR	ELECTROLYTIC CAPACITOR (C1, C2)	25V	0338	
292	WALK - IN - COOLER/FREEZER	(HUD) WIC/F GENR PANEL	CIRCUIT BREAKER	CIRCUIT BREAKERS (F-1, 6,7)	BBC S273 U16	0339	
293	WALK - IN - COOLER/FREEZER	(HUD) WIC/F GENR PANEL	CIRCUIT BREAKER	CIRCUIT BREAKERS (F-12, 13)	BBC S271 U16	0340	
294	WALK - IN - COOLER/FREEZER	(HUD) WIC/F GENR PANEL	CIRCUIT BREAKER	CIRCUIT BREAKERS (F4)	BBC S273 UIO	0341	








295	WALK - IN - COOLER/FREEZER	(HUD) WIC/F GENR PANEL	CIRCUIT BREAKER	CIRCUIT BREAKER (F5, 8,9,14)	BBC S271 UIO	0342	
296	WALK - IN - COOLER/FREEZER	(HUD) WIC/F GENR PANEL	CIRCUIT BREAKER	CIRCUIT BREAKER (F11)	BBC S271 U25	0343	
297	WALK - IN - COOLER/FREEZER	(HUD) WIC/F GENR PANEL	RELAY	THERMAL RELAY (F2) TELEMACH	LR1-D12316 A65	0344	
298	WALK - IN - COOLER/FREEZER	(HUD) WIC/F GENR PANEL	INDICATOR LAMP	SIGNAL LAMP	XB2-BV65, BA9S	0345	
299	WALK - IN - COOLER/FREEZER	(HUD) WIC/F GENR PANEL	INDICATOR LAMP	SIGNAL LAMP	XB2-BV64, BA9S	0346	
300	WALK - IN - COOLER/FREEZER	(HUD) WIC/F GENR PANEL	CONTACTOR	GENR. CONTACTOR (K1) (TELEMECANIQUE)	LC1-D253 MA65	0347	
301	WALK - IN - COOLER/FREEZER	(HUD) WIC/F GENR PANEL	AUXILIARY CONTACT BLOCK	AUX. CONTACTS FOR K1 & K2	LA1-D22A65	0348	

302	WALK - IN - COOLER/FREEZER	(HUD) WIC/F GENR PANEL	AUXILIARY CONTACT BLOCK	AUX CONTACTOR FOR GENR VOLTAGE (K4)	CA2 EN1 40M 4S	0349	
303	WALK - IN - COOLER/FREEZER	(HUD) WIC/F GENR PANEL	RC UNIT	RC-UNIT FOR K1, K2, K4 LA4DA1U	LA9-D09980	0350	
304	WALK - IN - COOLER/FREEZER	(HUD) WIC/F GENR PANEL	RELAY	MAINS VOLTAGE WATCHING UNIT (K6)	SY1553801 1PGS	0351	
305	WALK - IN - COOLER/FREEZER	(HUD) WIC/F GENR PANEL	RELAY	12V DC RELAYS (13 NOS) Zettler	AZ1010-3C-12DC	0352	
306	WALK - IN - COOLER/FREEZER	(HUD) WIC/F GENR PANEL	RELAY	TIME LAG RELAY (Kuhnuri)	VA10-100S, 12V	0353	
307	WALK - IN - COOLER/FREEZER	(HUD) WIC/F GENR PANEL	RELAY	CONTROL RELAY FOR AUTO START (K33)	S109256712, 12, 12V	0354	
308	WALK - IN - COOLER/FREEZER	(HUD) WIC/F GENR PANEL	RELAY	AUX. RELAY (Km 1&2) (Schier)	07.1200.20	0355	

309	WALK - IN - COOLER/FREEZER	(HUD) WIC/F GENR PANEL	METER	AMMETER	SACI (72x72)	0356	
310	WALK - IN - COOLER/FREEZER	(HUD) WIC/F GENR PANEL	METER	VOLTMETER	SACI (72x72)	0357	
311	WALK - IN - COOLER/FREEZER	(HUD) WIC/F GENR PANEL	CONTACTOR	MAINS CONTACTOR (K2) (TELEMECANIQUE)	LC1-D323M A65	0358	
312	WALK-IN-COOLER/FREEZER	FOSTER WIC COOLING UNIT	FAN MOTOR	CONDENSER FAN MOTOR		0359	
313	WALK-IN-COOLER/FREEZER	FOSTER WIC COOLING UNIT	FAN MOTOR	EVAPORATOR FAN MOTOR		0360	
314	WALK-IN-COOLER/FREEZER	FOSTER WIC COOLING UNIT	CAPACITOR	CAPACITOR FOR FAN MOTOR		0361	
315	WALK-IN-COOLER/FREEZER	FOSTER WIC COOLING UNIT	FAN BLADE	FAN BLADES		0362	

316	WALK-IN-COOLER/FREEZER	FOSTER WIC COOLING UNIT	THERMOSTAT	THERMOSTAT		0363	
317	WALK-IN-COOLER/FREEZER	FOSTER WIC COOLING UNIT	PRESSOSTAT	HP/LP SWITCH		0364	
318	WALK-IN-COOLER/FREEZER	FOSTER WIC COOLING UNIT	COMPRESSOR	COMPRESSOR L200/0037 380V 3 PHASE	15452500	0365	
319	WALK - IN - COOLER/FREEZER	(HUD) WIC/F GENR PANEL	BUTTON	PUSH BUTTON SWITCH	XB2-BA21	0366	
320	WALK - IN - COOLER/FREEZER	(HUD) WIC/F GENR PANEL	BUTTON	PUSH BUTTON SWITCH	XB2-BA31+BE102	0367	
321	WALK - IN - COOLER/FREEZER	(HUD) WIC/F GENR PANEL	METER	PHASE SEQUENCE METER	IRC4E 380V72x72	0368	
322	WALK - IN - FREEZER	(HUD) WIF LOMBARDINI DIESEL ENGINE	FILTER	OIL FILTER 8LD 740-2		0370	








323	WALK - IN - FREEZER	(HUD) WIF LOMBARDINI DIESEL ENGINE	FILTER	FUEL FILTER 8LD 740-2		0371	
324	WALK - IN - FREEZER	(HUD) WIF LOMBARDINI DIESEL ENGINE	FILTER	AIR FILTER CARTRIDGE 8LD 740-2		0372	
325	WALK - IN - FREEZER	(HUD) WIF LOMBARDINI DIESEL ENGINE	RING SET	PISTON RING SET STD 8LD 740-2		0373	
326	WALK - IN - FREEZER	(HUD) WIF LOMBARDINI DIESEL ENGINE	PISTON	PISTON COMPLETE, STD 8LD 740-2		0374	
327	WALK - IN - FREEZER	(HUD) WIF LOMBARDINI DIESEL ENGINE	BEARING	SHAFT BEARING STD 8LD 740-2		0375	
328	WALK - IN - FREEZER	(HUD) WIF LOMBARDINI DIESEL ENGINE	BEARING	SHAFT BEARING JP STD 8LD 740-2		0376	
329	WALK - IN - FREEZER	(HUD) WIF LOMBARDINI DIESEL ENGINE	BEARING	FRAME BEARING MIDDLE STD, 8LD 740-2		0377	

330	WALK - IN - FREEZER	(HUD) WIF LOMBARDINI DIESEL ENGINE	BEARING	FRAME BEARING VP, STD 8LD 740-2		0378	
331	WALK - IN - FREEZER	(HUD) WIF LOMBARDINI DIESEL ENGINE	NOZZLE	NOZZLE TIP 8LD 740-2		0379	
332	WALK - IN - FREEZER	(HUD) WIF LOMBARDINI DIESEL ENGINE	GASKET SET	GASKET 0.50 8LD 740-2		0380	
333	WALK - IN - FREEZER	(HUD) WIF LOMBARDINI DIESEL ENGINE	GASKET SET	GASKET 1.00 8LD 740-2		0381	
334	WALK - IN - FREEZER	(HUD) WIF LOMBARDINI DIESEL ENGINE	INJECTOR	FUEL INJ. HOSE PRESS (SL.11) 8LD 740-2		0382	
335	WALK - IN - FREEZER	(HUD) WIF LOMBARDINI DIESEL ENGINE	INJECTOR	FUEL INJ. HOSE PRESS (SL.12) 8LD 740-2		0383	
336	WALK - IN - FREEZER	(HUD) WIF LOMBARDINI DIESEL ENGINE	PUMP	FUEL PUMP 8LD 740-2		0384	








337	WALK - IN - FREEZER	(HUD) WIF LOMBARDINI DIESEL ENGINE	GASKET SET	SET OF GASKETS 8LD 740-2		0385	
338	WALK - IN - FREEZER	(HUD) WIF LOMBARDINI DIESEL ENGINE	SEAL	SHAFT SEAL JP 8LD 740-2		0386	
339	WALK - IN - FREEZER	(HUD) WIF LOMBARDINI DIESEL ENGINE	SEAL	SHAFT SEAL VP 8LD 740-2		0387	
340	WALK - IN - FREEZER	(HUD) WIF LOMBARDINI DIESEL ENGINE	VALVE	EXHAUST VALVE 8LD 740-2		0389	
341	WALK - IN - FREEZER	(HUD) WIF LOMBARDINI DIESEL ENGINE	VALVE	SUCTION VALVE 8LD 740-2		0390	
342	WALK - IN - FREEZER	(HUD) WIF LOMBARDINI DIESEL ENGINE	BELT	V BELT 8LD 740-2		0394	
343	WALK - IN - FREEZER	(HUD) WIF LOMBARDINI DIESEL ENGINE	CHARGER	BATTERY CHARGE CNTL 8LD 740-2		0395	

344	WALK - IN - FREEZER	(HUD) WIF LOMBARDINI DIESEL ENGINE	LINER	CYLINDER LINER STD 8LD 740-2		0396	
345	WALK - IN - FREEZER	(HUD) WIF LOMBARDINI DIESEL ENGINE	PISTON	PISTON COMPLETE+0.50 8LD 740-2		0397	
346	WALK - IN - FREEZER	(HUD) WIF LOMBARDINI DIESEL ENGINE	BEARING	FRAME BEARING JP-0.50 8LD 740-2		0399	
347	WALK - IN - FREEZER	(HUD) WIF LOMBARDINI DIESEL ENGINE	BEARING	FRAME BEARING JP-0.50 8LD 740-2		0400	
348	WALK - IN - FREEZER	(HUD) WIF LOMBARDINI DIESEL ENGINE	BEARING	FRAME BEARING MIDDLE-0.25 8LD 740-2		0401	
349	WALK - IN - FREEZER	(HUD) WIF LOMBARDINI DIESEL ENGINE	BEARING	FRAME BEARING MIDDLE-0.50 8LD 740-2		0402	
350	WALK - IN - FREEZER	(HUD) WIF LOMBARDINI DIESEL ENGINE	BEARING	FRAME BEARING VP-0.25 8LD 740-2		0403	








351	WALK - IN - FREEZER	(HUD) WIF LOMBARDINI DIESEL ENGINE	BEARING	FRAME BEARING VP-0.25 8LD 740-2		0404	
352	WALK - IN - FREEZER	(HUD) WIF LOMBARDINI DIESEL ENGINE	HEAD	CYLINDER HEAD COMPL 8LD 740-2		0405	
353	WALK - IN - COOLER	(HUD) WIF LOMBARDINI DIESEL ENGINE	FILTER	OIL FILTER 9LD 561-2		0408	
354	WALK - IN - COOLER	(HUD) WIF LOMBARDINI DIESEL ENGINE	FILTER	FUEL FILTER 9LD 561-2		0409	
355	WALK - IN - COOLER	(HUD) WIF LOMBARDINI DIESEL ENGINE	FILTER	AIR FILTER CARTRIDGE 9LD 561-2		0410	
356	WALK - IN - COOLER	(HUD) WIF LOMBARDINI DIESEL ENGINE	RING SET	PISTON RING SET, STD 9LD 561-2		0411	
357	WALK - IN - COOLER	(HUD) WIF LOMBARDINI DIESEL ENGINE	PISTON	PISTON COMPLETE STD 9LD 561-2		0412	

358	WALK - IN - COOLER	(HUD) WIF LOMBARDINI DIESEL ENGINE	BEARING	SHAFT BEARING STD 9LD 561-2		0413	
359	WALK - IN - COOLER	(HUD) WIF LOMBARDINI DIESEL ENGINE	BEARING	FRAME BEARING JP, STD 9LD 561-2		0414	
360	WALK - IN - COOLER	(HUD) WIF LOMBARDINI DIESEL ENGINE	BEARING	FRAME BEARING MIDDLE STD 9LD 561-2		0415	
361	WALK - IN - COOLER	(HUD) WIF LOMBARDINI DIESEL ENGINE	BEARING	FRAME BEARING VP, STD 9LD 561-2		0416	
362	WALK - IN - COOLER	(HUD) WIF LOMBARDINI DIESEL ENGINE	NOZZLE	NOZZLE TIP 9LD 561-2		0417	
363	WALK - IN - COOLER	(HUD) WIF LOMBARDINI DIESEL ENGINE	GASKET SET	GASKET 0..50 9LD 561-2		0418	
364	WALK - IN - COOLER	(HUD) WIF LOMBARDINI DIESEL ENGINE	GASKET SET	GASKET 1.00 9LD 561-2		0419	

365	WALK - IN - COOLER	(HUD) WIF LOMBARDINI DIESEL ENGINE	INJECTOR	FUEL INJ. HOSE, PRESS 9LD 561-2		0420	
366	WALK - IN - COOLER	(HUD) WIF LOMBARDINI DIESEL ENGINE	INJECTOR	FUEL INJ. HOSE, PRESS 9LD 561-2		0421	
367	WALK - IN - COOLER	(HUD) WIF LOMBARDINI DIESEL ENGINE	PUMP	FUEL PUMP 9LD 561-2		0422	
368	WALK - IN - COOLER	(HUD) WIF LOMBARDINI DIESEL ENGINE	GASKET SET	SET OF GASKETS 9LD 561-2		0423	
369	WALK - IN - COOLER	(HUD) WIF LOMBARDINI DIESEL ENGINE	SEAL	SHAFT SEAL JP 9LD 561-2		0424	
370	WALK - IN - COOLER	(HUD) WIF LOMBARDINI DIESEL ENGINE	VALVE	EXHAUST VALVE 9LD 561-2		0426	
371	WALK - IN - COOLER	(HUD) WIF LOMBARDINI DIESEL ENGINE	VALVE	SUCTION VALVE 9LD 561-2		0427	








372	WALK - IN - COOLER	(HUD) WIF LOMBARDINI DIESEL ENGINE	VALVE	VALVE CNTRL. SUCTION 9LD 561-2		0428	
373	WALK - IN - COOLER	(HUD) WIF LOMBARDINI DIESEL ENGINE	VALVE	SUCTION VALVE RUBBER 9LD 561-2		0430	
374	WALK - IN - COOLER	(HUD) WIF LOMBARDINI DIESEL ENGINE	CHARGER	BATTERY CHARGER CONTROL 9LD 561-2		0431	
375	WALK - IN - COOLER	(HUD) WIF LOMBARDINI DIESEL ENGINE	LINER	CYLINDER LINER, STD 9LD 561-2		0432	
376	WALK - IN - COOLER	(HUD) WIF LOMBARDINI DIESEL ENGINE	PISTON	PISTON COMPLETE + 0.50 9LD 561-2		0433	
377	WALK - IN - COOLER	(HUD) WIF LOMBARDINI DIESEL ENGINE	BEARING	SHAFT BEARING -0.25 9LD 561-2		0434	
378	WALK - IN - COOLER	(HUD) WIF LOMBARDINI DIESEL ENGINE	BEARING	FRAME BEARING. JP-0.25 9LD 561-2		0435	







379	WALK - IN - COOLER	(HUD) WIF LOMBARDINI DIESEL ENGINE	BEARING	FRAME BEARING JP-0.50 9LD 561-2		0436	
380	WALK - IN - COOLER	(HUD) WIF LOMBARDINI DIESEL ENGINE	BEARING	FRAME BEARING MIDDLE -0.50 9LD 561-2		0438	
381	WALK - IN - COOLER	(HUD) WIF LOMBARDINI DIESEL ENGINE	BEARING	FRAME BEARING VP-0.25 9LD 561-2		0439	
382	WALK - IN - COOLER	(HUD) WIF LOMBARDINI DIESEL ENGINE	PUMP	FUEL PUMP, FEEDING 9LD 561-2		0441	
383	WALK - IN - COOLER	(HUD) WIF LOMBARDINI DIESEL ENGINE	HEAD	CYLINDER HEAD COMPLETE 9LD 561-2		0442	
384	WALK - IN - COOLER	(HUD) WIF LOMBARDINI DIESEL ENGINE	SOLENOID	STOP SOLENOID COMPL 9LD 561-2		0445	
385	WALK - IN - COOLER/FREEZER	(FOS) WIC/F GEN ENGINE	BENDIX	STARTER BENDIX ASSY DM-188	45532003 A	0446	

386	WALK - IN - COOLER	(HUD) WIF LOMBARDINI DIESEL ENGINE	SOLENOID	STARTER SOLENOID 9LD 561-2		0447	
387	WALK - IN - COOLER	(HUD) WIF LOMBARDINI DIESEL ENGINE	STARTER MOTOR	STARTER ASSY COMPLETE 9LD 561-2		0448	
388	WALK - IN - COOLER	(HUD) WIF LOMBARDINI DIESEL ENGINE	GEAR	FLY-WHEEL RING GEAR 9LD 561-2		0449	
389	WALK - IN - COOLER	(HUD) WIF LOMBARDINI DIESEL ENGINE	BENDIX	STARTER BENDIX 9LD 561-2		0450	
390	WALK - IN - FREEZER	(HUD) WIF LOMBARDINI DIESEL ENGINE	SOLENOID	STARTER SOLENOID 8LD 740-2		0451	
391	WALK - IN - FREEZER	(HUD) WIF LOMBARDINI DIESEL ENGINE	STARTER MOTOR	STARTER ASSY. COMPLETE 8LD 740-2		0452	
392	WALK - IN - FREEZER	(HUD) WIF LOMBARDINI DIESEL ENGINE	GEAR	FLY-WHEEL RING GEAR 8LD 740-2		0453	








393	WALK - IN - FREEZER	(HUD) WIF LOMBARDINI DIESEL ENGINE	BENDIX	STARTER BENDIX 8LD 740-2		0454	
394	WALK - IN - FREEZER	(HUD) WIF COOLING UNIT	COMPRESSOR	COMPRESSOR FOR R 502 MANEUROP, HP-4VE	3-PH L-50	0457	
395	WALK - IN - FREEZER	(HUD) WIF COOLING UNIT	DRIER	DRIER DANFOSS DX 303		0458	
396	WALK - IN - COOLER	(HUD) WIF COOLING UNIT	CARBURETOR	CARBURETOR (COMPLETE) B & S M.252417 TY.0526		0459	
397	SERVO VOLTAGE STABILISER	Sagar 10 KVA / 3 Phase	TRANSFORMER	SENSING TRANSFORMER			
398	SERVO VOLTAGE STABILISER	Sagar 10 KVA / 3 Phase	METER	VOLTMETER (0-300V FOR 0-500V)			
399	SERVO VOLTAGE STABILISER	Sagar 10 KVA / 3 Phase	SWITCH	AUTO MANUAL SWITCH (12 WAY 2 POLE)			








400	SERVO VOLTAGE STABILISER	Sagar 10 KVA / 3 Phase	SWITCH	INPUT/OUTPUT SELECTOR SWITCH FOR VOLTMETER			
401	SERVO VOLTAGE STABILISER	Sagar 10 KVA / 3 Phase	SWITCH	PHASE SELECTOR SWITCH FOR VOLTMETER			
402	SERVO VOLTAGE STABILISER	Sagar 10 KVA / 3 Phase	INDICATOR LAMP	INPUT INDICATORS			
403	SERVO VOLTAGE STABILISER	Sagar 10 KVA / 3 Phase	PRINTED CIRCUIT BOARD	CONTROL PCB WITH CONNECTOR			
404	SERVO VOLTAGE STABILISER	Sagar 10 KVA / 3 Phase	PRINTED CIRCUIT BOARD	CUT-OFF PCB			
405	SERVO VOLTAGE STABILISER	Sagar 10 KVA / 3 Phase	SWITCH	PUSH SWITCH (INCREASE/DECREASE)			
406	SERVO VOLTAGE STABILISER	Sagar 10 KVA / 3 Phase	PRESET	POTENTIOMETER FOR OUTPUT ADJUSTMENT			








407	SERVO VOLTAGE STABILISER	Sagar 10 KVA / 3 Phase	VARIAC	DIMMER (VARIAC) ASSEMBLY			
408	SERVO VOLTAGE STABILISER	Sagar 10 KVA / 3 Phase	SERVO MOTOR	SERVO MOTOR			
409	SERVO VOLTAGE STABILISER	Sagar 10 KVA / 3 Phase	SWITCH	MICRO SWITCH			
410	SERVO VOLTAGE STABILISER	Sagar 10 KVA / 3 Phase	GEAR	GEAR ASSEMBLY (MOTOR/VARIAC GEAR)			
411	SERVO VOLTAGE STABILISER	Sagar 10 KVA / 3 Phase	PLATE	VARIAC COUPLING PLATE			
412	SERVO VOLTAGE STABILISER	Sagar 10 KVA / 3 Phase	TRANSFORMER	SERIES TRANSFORMER			
413	SERVO VOLTAGE STABILISER	Sagar 10 KVA / 3 Phase	CONTACTOR	CONTACTOR			







414	SERVO VOLTAGE STABILISER	Sagar 10 KVA / 3 Phase	CIRCUIT BREAKER	MCB			
415	SERVO VOLTAGE STABILISER	Sagar 10 KVA / 3 Phase	SWITCH	PUSH SWITCH TO BYPASS TIMER			
416	SERVO VOLTAGE STABILISER	Sagar 10 KVA / 3 Phase	SWITCH	CHANGE OVER RELAY			
417	SOLID STATE VOLTAGE STABILIZERS	SAGAR HPC-1KVA	TRANSFORMER	MAIN AUTO TRANSFORMER T1		0601	
418	SOLID STATE VOLTAGE STABILIZERS	SAGAR HPC-1KVA	TRANSFORMER	CONTROL TRANSFORMER (AUX) T2		0602	
419	SOLID STATE VOLTAGE STABILIZERS	SAGAR HPC-1KVA	PRINTED CIRCUIT BOARD	CONTROL PCB COMPLETE		0603	
420	SOLID STATE VOLTAGE STABILIZERS	SAGAR HPC-1KVA	RELAY	RELAYS (SINGLE CHANGEOVER) 24V, 750 OHMS	OEN 4R1-24(Spl)	0604	








421	SOLID STATE VOLTAGE STABILIZERS	SAGAR HPC-1KVA	RELAY	RELAYS (SINGLE CHANGEOVER) 24V, DC,750 OHMS	PLA HCC 1C-24	0605	
422	SOLID STATE VOLTAGE STABILIZERS	SAGAR HPC-1KVA	RELAY	RELAYS (DOUBLE CHANGEOVER) 24V, 750 OHMS	OEN 4R2-24 (spl)	0606	
423	SOLID STATE VOLTAGE STABILIZERS	SAGAR HPC-1KVA	RELAY	RELAYS (DOUBLE CHANGEOVER) 24V, 750 OHM	PLA HCC 2C-24	0607	
424	SOLID STATE VOLTAGE STABILIZERS	SAGAR HPC-1KVA	SWITCH	TIME DELAY BY-PASS SWITCH		0608	
425	SOLID STATE VOLTAGE STABILIZERS	SAGAR HPC-1KVA	CIRCUIT BREAKER	MINIATURE CIRCUIT BREAKER 1-POLE		0609	
426	SOLID STATE VOLTAGE STABILIZERS	SAGAR HPC-1KVA	METER	VOLTMETER CLASS 1.5		0610	
427	SOLID STATE VOLTAGE STABILIZERS	SAGAR HPC-1KVA	INDICATOR LAMP	JEWEL LAMP COMPLETE 230V		0611	

428	SOLID STATE VOLTAGE STABILIZERS	SAGAR HPC-1KVA	TERMINAL STRIP	OUTPUT TERMINAL STRIP 6 WAY		0612	
429	SOLID STATE VOLTAGE STABILIZERS	SAGAR HPC-1KVA	SWITCH	INPUT/OUTPUT SELECTOR SWITCH		0613	
430	SOLID STATE VOLTAGE STABILIZERS	SAGAR HPC-1KVA	SWITCH	ON/OFF SWITCH FOR VOLTMETER		0614	
431	SOLID STATE VOLTAGE STABILIZERS	SAGAR HPC-1KVA	CONNECTOR	PCB CONNECTOR STRIP XXXX		0615	
432	SOLID STATE VOLTAGE STABILIZERS	BLUE LINE 1KVA	TRANSFORMER	MAIN AUTO TRANSFORMER	VI 61	0616	
433	SOLID STATE VOLTAGE STABILIZERS	BLUE LINE 1KVA	TRANSFORMER	CONTROL TRANSFORMER-1	GA02	0617	
434	SOLID STATE VOLTAGE STABILIZERS	BLUE LINE 1KVA	TRANSFORMER	SENSING TRANSFORMER	AU24	0618	

435	SOLID STATE VOLTAGE STABILIZERS	BLUE LINE 1KVA	TRANSFORMER	CONTROL TRANSFORMER-2	GA03	0619	
436	SOLID STATE VOLTAGE STABILIZERS	BLUE LINE 1KVA	PRINTED CIRCUIT BOARD	PRINTED WIRED ASSEMBLY (PCB COMPLETE)	GB28	0620	
437	SOLID STATE VOLTAGE STABILIZERS	BLUE LINE 1KVA	CIRCUIT BREAKER	MINIATURE CIRCUIT BREAKER	CB 01	0621	
438	SOLID STATE VOLTAGE STABILIZERS	BLUE LINE 1KVA	SWITCH	TOGGLE SWITCH 3-WAY (INPUT/OUTPUT)	SW02	0622	
439	SOLID STATE VOLTAGE STABILIZERS	BLUE LINE 1KVA	METER	VOLTMETER CLASS 1.5	VM72	0623	
440	SOLID STATE VOLTAGE STABILIZERS	BLUE LINE AVR 1KVA	INDICATOR LAMP	LED STRIP WITH RESISTANCE	CS01	0624	
441	SOLID STATE VOLTAGE STABILIZERS	BLUE LINE 1KVA	INDICATOR LAMP	LED (RED)	LD01	0625	

442	SOLID STATE VOLTAGE STABILIZERS	BLUE LINE 1KVA	RELAY	RELAYS (SINGLE CONTACT)	RL01	0626	
443	SOLID STATE VOLTAGE STABILIZERS	BLUE LINE 1KVA	SWITCH	RELAYS (DOUBLE CONTACT)	RL02-04	0627	
444	SOLID STATE VOLTAGE STABILIZERS	BLUE LINE 1KVA	SWITCH	TIME DELAY BY-PASS SWITCH SW01	SW01	0628	
445	SOLID STATE VOLTAGE STABILIZERS	BLUE LINE 1KVA	TERMINAL STRIP	OUTPUT TERMINAL STRIP 6-WAY	HT06	0629	
446	SOLID STATE VOLTAGE STABILIZERS	BLUE LINE 1KVA	CONNECTOR	PWA CONNECTOR STRIP		0630	
447	SOLID STATE VOLTAGE STABILIZERS	BLUE LINE 1KVA	CONNECTOR	UNIT CONNECTOR STRIP	HT06	0631	
448	SERVO VOLTAGE STABILIZERS	SERVAL STABILIZERS	TRANSISTER	TRANSISTOR CN 100		0632	

449	SERVO VOLTAGE STABILIZERS	SERVEL STABILIZERS 10 KVA / 3 Phase	TRANSISTER	TRANSISTOR BC 177		0633	
450	SERVO VOLTAGE STABILIZERS	SERVEL STABILIZERS 10 KVA / 3 Phase	DIODE	DIODE EC 4003		0634	
451	SERVO VOLTAGE STABILIZERS	SERVEL STABILIZERS 10 KVA / 3 Phase	DIODE	ZENER DIODES 5.6 V		0635	
452	SERVO VOLTAGE STABILIZERS	SERVEL STABILIZERS 10 KVA / 3 Phase	THYRISTOR	THYRISTORS 2N 6565		0636	
453	SERVO VOLTAGE STABILIZERS	SERVEL STABILIZERS 10 KVA / 3 Phase	IC	INTEGRATED CIRCUIT (IC-1/2) LM324		0637	
454	SERVO VOLTAGE STABILIZERS	SERVEL STABILIZERS 10 KVA / 3 Phase	PRESET	PRESET 2K/2K2		0638	
455	SERVO VOLTAGE STABILIZERS	SERVEL STABILIZERS 10 KVA / 3 Phase	CAPACITOR	CAPACITOR, 220 MFD		0639	








456	SERVO VOLTAGE STABILIZERS	SERVEL STABILIZERS 10 KVA / 3 Phase	SWITCH	SWITCH, 5 A - 2 WAY		0640	
457	SERVO VOLTAGE STABILIZERS	SERVEL STABILIZERS 10 KVA / 3 Phase	SWITCH	SWITCH PUSH-TO-ON		0641	
458	SERVO VOLTAGE STABILIZERS	SERVEL STABILIZERS 10 KVA / 3 Phase	INDICATOR LAMP	NEON LAMP		0642	
459	SERVO VOLTAGE STABILIZERS	SERVEL STABILIZERS 10 KVA / 3 Phase	METER	VOLTMETER	C-400-C	0643	
460	SERVO VOLTAGE STABILIZERS	SERVEL STABILIZERS 10 KVA / 3 Phase	CONNECTOR	PCB CONNECTOR 12-PIN	C-502	0644	
461	SERVO VOLTAGE STABILIZERS	SERVEL STABILIZERS 10 KVA / 3 Phase	CONNECTOR	PCB CONNECTOR 10-PIN		0645	
462	SERVO VOLTAGE STABILIZERS	SERVEL STABILIZERS 10 KVA / 3 Phase	HANDLE	HANDLE		0646	


463	SERVO VOLTAGE STABILIZERS	SERVEL STABILIZERS 10 KVA / 3 Phase	RELAY	RELAYS 4R-2-24	C-00A	0647	
464	SERVO VOLTAGE STABILIZERS	SERVEL STABILIZERS 10 KVA / 3 Phase	TRANSFORMER	TRANSFORMER 1.0 KVA (MAIN AUT-TX)	B-149	0648	
465	SERVO VOLTAGE STABILIZERS	SERVEL STABILIZERS 10 KVA / 3 Phase	TRANSFORMER	SENSING TRANSFORMER	B-166	0649	
466	SERVO VOLTAGE STABILIZERS	SERVEL STABILIZERS 10 KVA / 3 Phase	IC	REGULATOR IC 7812		0650	
467	SERVO VOLTAGE STABILIZERS	SERVEL STABILIZERS 10 KVA / 3 Phase	IC	REGULATOR IC 317		0651	
468	SERVO VOLTAGE STABILIZERS	SERVEL STABILIZERS 10 KVA / 3 Phase	CAPACITOR	CAPACITOR 470 UF		0652	
469	SERVO VOLTAGE STABILIZERS	SERVEL STABILIZERS 10 KVA / 3 Phase	CAPACITOR	CAPACITOR 470 UF		0653	








470	SERVO VOLTAGE STABILIZERS	SERVEL STABILIZERS 10 KVA / 3 Phase	TERMINAL STRIP	TERMINAL STRIP		0654	
471	SERVO VOLTAGE STABILIZERS	SERVEL STABILIZERS 10 KVA / 3 Phase	TERMINAL STRIP	TERMINAL STRIP	C-450-15A	0655	
472	SERVO VOLTAGE STABILIZERS	SERVEL STABILIZERS 10 KVA / 3 Phase	CIRCUIT BREAKER	M.C.B 16A	C-166-16A	0656	
473	SERVO VOLTAGE STABILIZERS	SERVEL STABILIZERS 10 KVA / 3 Phase	FILTER	FILTER (CKT) (SURGE SUPPRESSOR)	C-749	0658	
474	SERVO VOLTAGE STABILIZERS	SERVEL STABILIZERS 10 KVA / 3 Phase	PRINTED CIRCUIT BOARD	PCB (SE-01-9)	C-746	0659	
475	SERVO VOLTAGE STABILIZERS	SERVEL STABILIZERS 10 KVA / 3 Phase	SWITCH	TOGGLE SWITCH SPDT,(INPUT/OUTPUT)		0660	
476	SERVO VOLTAGE STABILIZERS	SERVAL STABILIZERS	SWITCH	TOGGLE SWITCH DPDT (AUTO/MANUAL)		0661	








477	SERVO VOLTAGE STABILIZERS	SERVEL STABILIZERS 10 KVA / 3 Phase	SWITCH	ROTARY SWITCH 3S36 (INPUT/OUTPUT)		0662	
478	SERVO VOLTAGE STABILIZERS	SERVEL STABILIZERS 10 KVA / 3 Phase	SWITCH	ROTARY SWITCH 4S44 (LINE/PH SELECTOR)		0663	
479	SERVO VOLTAGE STABILIZERS	SERVEL STABILIZERS 10 KVA / 3 Phase	SWITCH	SWITCH PUSH-TO-ON		0664	
480	SERVO VOLTAGE STABILIZERS	SERVEL STABILIZERS 10 KVA / 3 Phase	SWITCH	MICRO-SWITCH		0665	
481	SERVO VOLTAGE STABILIZERS	SERVEL STABILIZERS 10 KVA / 3 Phase	PRESET	POTENTIOMETER 1K/1W		0666	
482	SERVO VOLTAGE STABILIZERS	SERVEL STABILIZERS 10 KVA / 3 Phase	CONNECTOR	PCB EDGE CONNECTOR 12-PIN		0667	
483	SERVO VOLTAGE STABILIZERS	SERVEL STABILIZERS 10 KVA / 3 Phase	CONNECTOR	RACK/PANEL CONNECTOR 8-PIN		0668	








484	SERVO VOLTAGE STABILIZERS	SERVEL STABILIZERS 10 KVA / 3 Phase	CONNECTOR	RACK/PANEL CONNECTOR 16-PIN		0669	
485	SERVO VOLTAGE STABILIZERS	SERVEL STABILIZERS 10 KVA / 3 Phase	TERMINAL STRIP	TERMINAL STRIP 30A		0670	
486	SERVO VOLTAGE STABILIZERS	SERVEL STABILIZERS 10 KVA / 3 Phase	TERMINAL STRIP	TERMINAL STRIP 60A		0671	
487	SERVO VOLTAGE STABILIZERS	SERVEL STABILIZERS 10 KVA / 3 Phase	SERVO MOTOR	SYNCHRONOUS MOTOR 3 KG/CM TORQUE		0672	
488	SERVO VOLTAGE STABILIZERS	SERVEL STABILIZERS 10 KVA / 3 Phase	SERVO MOTOR	SYNCHRONOUS MOTOR 10 KG/CM TORQUE		0673	
489	SERVO VOLTAGE STABILIZERS	SERVEL STABILIZERS 10 KVA / 3 Phase	R C UNIT	R C NETWORK (FOR SYNC MOTOR)		0674	
490	SERVO VOLTAGE STABILIZERS	SERVEL STABILIZERS 10 KVA / 3 Phase	GEAR	GEARS, 60 TEETH (FOR VARIAC)		0675	








491	SERVO VOLTAGE STABILIZERS	SERVEL STABILIZERS 10 KVA / 3 Phase	GEAR	GEARS FOR 3 KG/CM SYN MOTOR		0676	
492	SERVO VOLTAGE STABILIZERS	SERVEL STABILIZERS 10 KVA / 3 Phase	GEAR	GEARS FOR 10 KG/CM SYN MOTOR		0677	
493	SERVO VOLTAGE STABILIZERS	SERVEL STABILIZERS 10 KVA / 3 Phase	METER	VOLTMETER 0-300 V (72X72 MM)		0678	
494	SERVO VOLTAGE STABILIZERS	SERVEL STABILIZERS 10 KVA / 3 Phase	METER	VOLTMETER 0-500 V (96X96 MM)		0679	
495	SERVO VOLTAGE STABILIZERS	SERVEL STABILIZERS 10 KVA / 3 Phase	CIRCUIT BREAKER	M.C.B 2-PH 50 AMPS		0680	
496	SERVO VOLTAGE STABILIZERS	SERVEL STABILIZERS 10 KVA / 3 Phase	CIRCUIT BREAKER	M.C.B 3-PH 32 AMPS		0681	
497	SERVO VOLTAGE STABILIZERS	SERVEL STABILIZERS 10 KVA / 3 Phase	CIRCUIT BREAKER	M.C.C.B 50 AMPS		0682	

498	SERVO VOLTAGE STABILIZERS	SERVEL STABILIZERS 10 KVA / 3 Phase	COIL	CONTACTOR 25 AMPS		0683	
499	SERVO VOLTAGE STABILIZERS	SERVEL STABILIZERS 10 KVA / 3 Phase	COIL	COIL FOR 25A CONTACTOR		0684	
500	SERVO VOLTAGE STABILIZERS	SERVEL STABILIZERS 10 KVA / 3 Phase	CONTACTOR	CONTACTOR 55 AMPS		0685	
501	SERVO VOLTAGE STABILIZERS	SERVEL STABILIZERS 10 KVA / 3 Phase	COIL	COIL FOR 55A CONTACTOR		0686	
502	SERVO VOLTAGE STABILIZERS	SERVEL STABILIZERS 10 KVA / 3 Phase	PRINTED CIRCUIT BOARD	LED PCB ASSEMBLY 1-PH		0687	
503	SERVO VOLTAGE STABILIZERS	SERVEL STABILIZERS 10 KVA / 3 Phase	PRINTED CIRCUIT BOARD	LED PCB ASSEMBLY 3-PH UNBALANCE		0688	
504	SERVO VOLTAGE STABILIZERS	SERVEL STABILIZERS 10 KVA / 3 Phase	PRINTED CIRCUIT BOARD	CONTROL PCB (THYRISTOR TYPE)		0689	








505	SERVO VOLTAGE STABILIZERS	SERVEL STABILIZERS 10 KVA / 3 Phase	PRINTED CIRCUIT BOARD	CUT-OFF PCB FOR 3-PH UNBALANCE		0690	
506	SERVO VOLTAGE STABILIZERS	SERVEL STABILIZERS 10 KVA / 3 Phase	TRANSFORMER	SENSING TRANSFORMER FOR 1-PHASE		0691	
507	SERVO VOLTAGE STABILIZERS	SERVEL STABILIZERS 10 KVA / 3 Phase	VARIAC	VARIAC 28 AMPS 1-PH		0692	
508	SERVO VOLTAGE STABILIZERS	SERVEL STABILIZERS 10 KVA / 3 Phase	VARIAC	VARIAC 28 AMPS 2-PH		0693	
509	SERVO VOLTAGE STABILIZERS	SERVEL STABILIZERS 10 KVA / 3 Phase	VARIAC	VARIAC 28 AMPS 3-PH		0694	
510	SERVO VOLTAGE STABILIZERS	SERVEL STABILIZERS 10 KVA / 3 Phase	CARBON BRUSH	CARBON BRUSH FOR 28A VARIAC		0695	
511	SERVO VOLTAGE STABILIZERS	SERVEL STABILIZERS 10 KVA / 3 Phase	PLATE	SET OF MOVING & FIXED CONTACT PLATES		0696	

512	SERVO VOLTAGE STABILIZERS	SERVEL STABILIZERS 10 KVA / 3 Phase	HOLDER	OUTPUT INDICATING LAMP HOLDER		0697	
513	SERVO VOLTAGE STABILIZERS	SERVEL STABILIZERS 10 KVA / 3 Phase	HOLDER	LIMIT INDICATING LAMP HOLDER		0698	
514	SERVO VOLTAGE STABILIZERS	SERVEL STABILIZERS 10 KVA / 3 Phase	INDICATOR LAMP	NEON LAMP		0699	
515	SOLID STATE VOLTAGE STABILIZERS	GBM STABILIZERS	METER	VOLTMETER, 0-300 V, 96X96 MM		0700	
516	SOLID STATE VOLTAGE STABILIZERS	GBM STABILIZERS	CIRCUIT BREAKER	M.C.B., 5 AMPS		0701	
517	SOLID STATE VOLTAGE STABILIZERS	GBM STABILIZERS	SWITCH	PUSH BUTTON SWITCH		0702	
518	SOLID STATE VOLTAGE STABILIZERS	GBM STABILIZERS	PRESET	PRESET, 2K2		0703	








519	SOLID STATE VOLTAGE STABILIZERS	GBM STABILIZERS	TRANSISTER	TRANSISTOR, 2N3501		0704	
520	SOLID STATE VOLTAGE STABILIZERS	GBM STABILIZERS	TRANSISTER	TRANSISTOR, BC157		0705	
521	SOLID STATE VOLTAGE STABILIZERS	GBM STABILIZERS	TRANSISTER	TRANSISTOR, BC147		0706	
522	SOLID STATE VOLTAGE STABILIZERS	GBM STABILIZERS	DIODE	ZENER DIODE, 9.1 V		0707	
523	SOLID STATE VOLTAGE STABILIZERS	GBM STABILIZERS	DIODE	ZENER DIODE, 6.3 V		0708	
524	SOLID STATE VOLTAGE STABILIZERS	GBM STABILIZERS	CAPACITOR	CAPACITOR ,10UF, ELECTROLYTE		0709	
525	SOLID STATE VOLTAGE STABILIZERS	GBM STABILIZERS	CAPACITOR	CAPACITOR, 100 UF, ELECTROLYTE		0710	

526	SOLID STATE VOLTAGE STABILIZERS	GBM STABILIZERS	CAPACITOR	CAPACITOR, 220 UF, ELECTROLYTE		0711	
527	SOLID STATE VOLTAGE STABILIZERS	GBM STABILIZERS	DIODE	DIODE, 1N4007		0712	
528	SOLID STATE VOLTAGE STABILIZERS	GBM STABILIZERS	THYRISTOR	SCR ,S106M		0713	
529	SOLID STATE VOLTAGE STABILIZERS	GBM STABILIZERS	SWITCH	SPDT SWITCH		0714	
530	SOLID STATE VOLTAGE STABILIZERS	GBM STABILIZERS	INDICATOR LAMP	LED, RED		0715	
531	SOLID STATE VOLTAGE STABILIZERS	GBM STABILIZERS	INDICATOR LAMP	LED, GREEN		0716	
532	SOLID STATE VOLTAGE STABILIZERS	GBM STABILIZERS	PRINTED CIRCUIT BOARD	PCB ASSEMBLY ,'UNIK', COMPLETE		0717	






533	SOLID STATE VOLTAGE STABILIZERS	GBM STABILIZERS	TRANSFORMER	SENSING TRANSFORMER	TRS	0718	
534	SOLID STATE VOLTAGE STABILIZERS	GBM STABILIZERS	TRANSFORMER	MAINS TRANSFORMER	TRM	0719	
535	SOLID STATE VOLTAGE STABILIZERS	GBM STABILIZERS	RELAY	RELAY, 18V DC 2C/O, OEN/GM/RMD		0720	
536	SOLID STATE VOLTAGE STABILIZERS	SAGAR HPC-1KVA	TRANSFORMER	MAIN AUTO TRANSFORMER,T1		0721	
537	SOLID STATE VOLTAGE STABILIZERS	SAGAR HPC-1KVA	RELAY	RELAY 24V.(SINGLE CHE-OVER)	OEN WD 24	0722	
538	SOLID STATE VOLTAGE STABILIZERS	SAGAR HPC-1KVA	CIRCUIT BREAKER	MINIATURE CIRCUIT BREAKER,1-POLE		0723	
539	ILR/FREEZER	VESTFROST SB 140 / MK 300	COMPRESSOR	COMPRESSOR TF3 5AT COMPLETE 102U2046		0244	

540	ILR/FREEZER	VESTFROSTSB 140-300 / MK 140	DRIER	FILTER DRIER 20 GRAM		0245	
541	ILR/FREEZER	VESTFROST SB 140 / MK140	GASKET SET	RUBBER GASKET F140 + 201		0246	
542	DEEP FREEZER	VESTFROST SB 140 / SB 300	INDICATOR LAMP	PILOT LAMP GREEN / RED		0247	
543	DEEP FREEZER	VESTFROST SB 140 / SB 301	THERMOSTAT	THERMOSTAT(FREEZER) 077B 2007/2149		0248	
544	ILR/FREEZER	VESTFROST SB 140 / MK 300	STARTING DEVICE	STARTING DEVICE 117U4103		0249	
545	DEEP FREEZER	VESTFROST SB 140 / SB 300	SWITCH	FAST FREEZE SWITCH YELLOW		0250	
546	DEEP FREEZER	VESTFROSTSB 140	CONTROL PANEL	CONTROL PANEL WHITE		0251	

547	ILR/FREEZER	VESTFROST SB 140 -300 / MK 140	RUBBER DISC	RUBBER DISC FOR FOOT		0252	
548	ILR/FREEZER	VESTFROST SB 140 -300 / MK 140	FOOT WITH PIN	FOOT WITH PIN 23 MM		0253	
549	ILR/FREEZER	VESTFROST SB 140 / MK 140	HINGE	HINGE (73-09-91 / 50-60- 13)		0254	
550	ILR/FREEZER	VESTFROST SB 140 -300 / MK 140	SCREEN	MOTOR SCREEN		0255	
551	ILR/FREEZER	VESTFROST SB 140 -300 / MK 140	HANDLE	HANDLE WITH LOCK		0256	
552	ICE LINED REFRIGERAT OR	VESTFROST MK 140	COMPRESSOR	COMPRESSOR TFS 4AT COMPLETE 102 U2047		0257	
553	ICE LINED REFRIGERAT OR	VESTFROST MK 140	THERMOSTAT	THERMOSTAT (ILR) 077 B 0030		0258	

554	ICE LINED REFRIGERATOR	VESTFROST MK 140	STARTING DEVICE	STARTING DEVICE (4AT) 117 U 4159		0259	
555	ICE LINED REFRIGERATOR	VESTFROST MK 140	INDICATOR LAMP	PILOT LAMP GREEN		0260	
556	ILR/FREEZER	VESTFROST SB 300 / MK 140	CONTROL PANEL	CONTROL PANEL		0261	
557	DEEP FREEZER	VESTFROST SB 300	COMPRESSOR	COMPRESSOR FR7.5B COMPLETE 103U2764		0262	
558	DEEP FREEZER	VESTFROST SB 300	GASKET SET	RUBBER GASKET F 300 + 396		0263	
559	DEEP FREEZER	VESTFROST SB 300	STARTING DEVICE	STARTING DEVICE (7.5) 103 N 0011		0264	
560	DEEP FREEZER	VESTFROST SB 300	HINGE	HINGE SB 300-HF 396		0265	





561	ILR/FREEZER	VESTFROST SB 140 / MK 300	COMPRESSOR	COMPRESSOR FR 6B COMPLETE		0455	
562	ILR/FREEZER	VESTFROST SB 140 / MK 300	STARTING DEVICE	STARTING DEVICE FR6B 7038181		0456	
563	ICE LINED REFRIGERAT OR	HAIER HBC 200	COVER BOARD HANDLE	COVER BOARD OF HANDLE	70401045		
564	ICE LINED REFRIGERAT OR	HAIER HBC 200	SCREW	SCREW	77050002		
565	ICE LINED REFRIGERAT OR	HAIER HBC 200	HANDLE	HANDLE GROUP	70804793		
566	ICE LINED REFRIGERAT OR	HAIER HBC 200	LOCK	LOCK	70804244		
567	ICE LINED REFRIGERAT OR	HAIER HBC 200	FOAMING LID	FOAMING LID	70808546		

568	ICE LINED REFRIGERATOR	HAIER HBC 200	INNER FOAM LID (BIG)	INNER FOAM LID	70504284		
569	ICE LINED REFRIGERATOR	HAIER HBC 200	INNER FOAM LID (LITTLE)	INNER FOAM LID	70504285		
570	ICE LINED REFRIGERATOR	HAIER HBC 200	INNER SEAL	INNER SEAL	70202880		
571	ICE LINED REFRIGERATOR	HAIER HBC 200	INNER FRAME	INNER FRAME	70202695		
572	ICE LINED REFRIGERATOR	HAIER HBC 200	OUTER CABINET	OUTER CABINET	70808485		
573	ICE LINED REFRIGERATOR	HAIER HBC 200	ICE PACK	ICE PACK	70202851		
574	ICE LINED REFRIGERATOR	HAIER HBC 200	INNER TANK	INNER TANK	70808729		

575	ICE LINED REFRIGERATOR	HAIER HBC 200	FOAM FRAME(BACK)	FOAM FRAME(BACK)	70504232		
576	ICE LINED REFRIGERATOR	HAIER HBC 200	FOAM FRAME (LEFT)	FOAM FRAME (LEFT)	70504230		
577	ICE LINED REFRIGERATOR	HAIER HBC 200	FOAM FRAME(BOTTOM)	FOAM FRAME(BOTTOM)	70504236		
578	ICE LINED REFRIGERATOR	HAIER HBC 200	FOAM FRAME (FRONT)	FOAM FRAME (FRONT)	70504231		
579	ICE LINED REFRIGERATOR	HAIER HBC 200	FOAM FRAME (STAND)	FOAM FRAME (STAND)	70504237		
580	ICE LINED REFRIGERATOR	HAIER HBC 200	FOAM FRAME (MID)	FOAM FRAME (MID)	70504238		
581	ICE LINED REFRIGERATOR	HAIER HBC 200	FOAM FRAME (RIGHT)	FOAM FRAME (RIGHT)	70504229		


582	ICE LINED REFRIGERATOR	HAIER HBC 200	LOCK NOSE	LOCK NOSE	70103231		
583	ICE LINED REFRIGERATOR	HAIER HBC 200	SCREW	SCREW	77010001		
584	ICE LINED REFRIGERATOR	HAIER HBC 200	SCREW	SCREW	77050021		
585	ICE LINED REFRIGERATOR	HAIER HBC 200	CONTROL PANEL	CONTROL PANEL	70202720		
586	ICE LINED REFRIGERATOR	HAIER HBC 200	THRMOMETER	THRMOMETER	74090718		
587	ICE LINED REFRIGERATOR	HAIER HBC 200	INDICATOR LIGHT GREEN	INDICATOR LIGHT GREEN	75050008		
588	ICE LINED REFRIGERATOR	HAIER HBC 200	THERMOSTAT KNOB	THERMOSTAT KNOB	72040122		

589	ICE LINED REFRIGERATOR	HAIER HBC 200	SCREW	SCREW			
590	ICE LINED REFRIGERATOR	HAIER HBC 200	THERMOSTAT	THERMOSTAT	70701364		
591	ICE LINED REFRIGERATOR	HAIER HBC 200	CONTROL PANEL WIRE	CONTROL PANEL WIRE	70401609		
592	ICE LINED REFRIGERATOR	HAIER HBC 200	WIRE	WIRE			
593	ICE LINED REFRIGERATOR	HAIER HBC 200	WIRE CLIP	WIRE CLIP	71250271		
594	ICE LINED REFRIGERATOR	HAIER HBC 200	COMPRESSOR SUPPORTER	COMPRESSOR SUPPORTER	70802854		
595	ICE LINED REFRIGERATOR	HAIER HBC 200	WIRE CLIP	WIRE CLIP	72060002		



596	ICE LINED REFRIGERATOR	HAIER HBC 200	SCREW	SCREW	77010024	
597	ICE LINED REFRIGERATOR	HAIER HBC 200	GROUND SCREW	GROUND SCREW	75020010	
598	ICE LINED REFRIGERATOR	HAIER HBC 200	COMPRESSOR SPRING WASHER	COMPRESSOR SPRING WASHER	75020136	
599	ICE LINED REFRIGERATOR	HAIER HBC 200	COMPRESSOR WASHER	COMPRESSOR WASHER	75020137	
600	ICE LINED REFRIGERATOR	HAIER HBC 200	COMPRESSOR SLEEVES	COMPRESSOR SLEEVES	75020305	
601	ICE LINED REFRIGERATOR	HAIER HBC 200	RUBBER SPACER	RUBBER SPACER	75020001	
602	ICE LINED REFRIGERATOR	HAIER HBC 200	STARTING CAPACITOR	STARTING CAPACITOR	70701332	

603	ICE LINED REFRIGERATOR	HAIER HBC 200	COVER	COVER			
604	ICE LINED REFRIGERATOR	HAIER HBC 200	STARTING RELAY	STARTING RELAY			
605	ICE LINED REFRIGERATOR	HAIER HBC 200	CORD RELIEF	CORD RELIEF			
606	ICE LINED REFRIGERATOR	HAIER HBC 200	COMPRESSOR	COMPRESSOR			
607	ICE LINED REFRIGERATOR	HAIER HBC 200	FAN MOTOR	FAN	75030020		
608	ICE LINED REFRIGERATOR	HAIER HBC 200	CONDENSER	CONDENSER	70701369		
609	ICE LINED REFRIGERATOR	HAIER HBC 200	DISCHARGE TUBE	DISCHARGE TUBE	70701368		

610	ICE LINED REFRIGERATOR	HAIER HBC 200	SCREW	SCREW	77050021	
611	ICE LINED REFRIGERATOR	HAIER HBC 200	NUT	NUT	77050003	
612	ICE LINED REFRIGERATOR	HAIER HBC 200	HOT SHORTEN TUBE	HOT SHORTEN TUBE	79020006	
613	ICE LINED REFRIGERATOR	HAIER HBC 200	FILTER DRIER	FILTER DRIER	74180002	
614	ICE LINED REFRIGERATOR	HAIER HBC 200	ENGINE ROOM COVER	ENGINE ROOM COVER	71210004	
615	ICE LINED REFRIGERATOR	HAIER HBC 200	WASHER	WASHER	72130038	
616	ICE LINED REFRIGERATOR	HAIER HBC 200	SCREW	SCREW	77010036	

617	ICE LINED REFRIGERATOR	HAIER HBC 200	HINGE	HINGES	78090002		
618	ICE LINED REFRIGERATOR	HAIER HBC 200	SCREW	SCREW	77050002		
619	ICE LINED REFRIGERATOR	HAIER HBC 200	BOTTOM HINGE COVER	BOTTOM HINGE COVER	72040011		
620	ICE LINED REFRIGERATOR	HAIER HBC 200	TOP HINGE COVER	TOP HINGE COVER	72040003		
621	ICE LINED REFRIGERATOR	HAIER HBC 200	COMPARTMENT GRILL	COMPARTMENT GRILL	72220007		
622	ICE LINED REFRIGERATOR	HAIER HBC 200	SCREW	SCREW	77050058		
623	ICE LINED REFRIGERATOR	HAIER HBC 70	COVER BOARD HANDLE	COVER BOARD HANDLE	70401045		

624	ICE LINED REFRIGERATOR	HAIER HBC 70	SCREW	SCREW	77050002		
625	ICE LINED REFRIGERATOR	HAIER HBC 70	HANDLE	HANDLE GROUP	70804793		
626	ICE LINED REFRIGERATOR	HAIER HBC 70	LOCK	LOCK	70804244		
627	ICE LINED REFRIGERATOR	HAIER HBC 70	FOAMING LID	FOAMING LID	70808545		
628	ICE LINED REFRIGERATOR	HAIER HBC 70	INNER FOAM LID (BIG)	INNER FOAM LID	70504285		
629	ICE LINED REFRIGERATOR	HAIER HBC 70	INNER SEAL	INNER SEAL	70202879		
630	ICE LINED REFRIGERATOR	HAIER HBC 70	INNER FRAME	INNER-FRAME	70202696		








631	ICE LINED REFRIGERATOR	HAIER HBC 70	OUTER CABINET	OUTER CABINET	70808486		
632	ICE LINED REFRIGERATOR	HAIER HBC 70	ICE PACK	ICE PACK	70202851		
633	ICE LINED REFRIGERATOR	HAIER HBC 70	INNER TANK	INNER TANK	70808728		
634	ICE LINED REFRIGERATOR	HAIER HBC 70	FOAM FRAME(BACK)	FOAM FRAME(BACK)	70504234		
635	ICE LINED REFRIGERATOR	HAIER HBC 70	FOAM FRAME (LEFT)	FOAM FRAME (LEFT)	70504230		
636	ICE LINED REFRIGERATOR	HAIER HBC 70	FOAM FRAME(BOTTOM)	FOAM FRAME(BOTTOM)	70504235		
637	ICE LINED REFRIGERATOR	HAIER HBC 70	FOAM FRAME (FRONT)	FOAM FRAME (FRONT)	70504233		

638	ICE LINED REFRIGERATOR	HAIER HBC 70	FOAM FRAME (STAND)	FOAM FRAME (STAND)	70504237		
639	ICE LINED REFRIGERATOR	HAIER HBC 70	FOAM FRAME (MID)	FOAM FRAME (MID)	70504238		
640	ICE LINED REFRIGERATOR	HAIER HBC 70	FOAM FRAME (RIGHT)	FOAM FRAME (RIGHT)	70504229		
641	ICE LINED REFRIGERATOR	HAIER HBC 70	LOCK NOSE	LOCK NOSE	70103231		
642	ICE LINED REFRIGERATOR	HAIER HBC 70	SCREW	SCREW	77050051		
643	ICE LINED REFRIGERATOR	HAIER HBC 70	SCREW	SCREW	77010049		
644	ICE LINED REFRIGERATOR	HAIER HBC 70	CONTROL PANEL	CONTROL PANEL	70202720		

645	ICE LINED REFRIGERATOR	HAIER HBC 70	THERMOMETER	THERMOMETER	74090718		
646	ICE LINED REFRIGERATOR	HAIER HBC 70	INDICATOR LIGHT GREEN	INDICATOR LIGHT GREEN	75050008		
647	ICE LINED REFRIGERATOR	HAIER HBC 70	THERMOSTAT KNOB	THERMOSTAT KNOB	72040122		
648	ICE LINED REFRIGERATOR	HAIER HBC 70	SCREW	SCREW			
649	ICE LINED REFRIGERATOR	HAIER HBC 70	THERMOSTAT	THERMOSTAT	70701364		
650	ICE LINED REFRIGERATOR	HAIER HBC 70	CONTROL PANEL WIRE	CONTROL PANEL WIRE	70401609		
651	ICE LINED REFRIGERATOR	HAIER HBC 70	WIRE	WIRE			

652	ICE LINED REFRIGERATOR	HAIER HBC 70	WIRE CLIP	WIRE CLIP	71250271		
653	ICE LINED REFRIGERATOR	HAIER HBC 70	COMPRESSOR SUPPORTER	COMPRESSOR SUPPORTER	71190002		
654	ICE LINED REFRIGERATOR	HAIER HBC 70	WIRE CLIP	WIRE CLIP	72060002		
655	ICE LINED REFRIGERATOR	HAIER HBC 70	SCREW	SCREW	77010004		
656	ICE LINED REFRIGERATOR	HAIER HBC 70	GROUND SCREW	GROUND SCREW	75020010		
657	ICE LINED REFRIGERATOR	HAIER HBC 70	COMPRESSOR SPRING WASHER	COMPRESSOR SPRING WASHER	75020136		
658	ICE LINED REFRIGERATOR	HAIER HBC 70	COMPRESSOR WASHER	COMPRESSOR WASHER	75020137		








659	ICE LINED REFRIGERATOR	HAIER HBC 70	COMPRESSOR SLEEVES	COMPRESSOR SLEEVES	75020305	
660	ICE LINED REFRIGERATOR	HAIER HBC 70	RUBBER SPACER	RUBBER SPACER	75020001	
661	ICE LINED REFRIGERATOR	HAIER HBC 70	STARTING CAPACITOR	STARTING CAPACITOR	70701331	
662	ICE LINED REFRIGERATOR	HAIER HBC 70	COVER	COVER	70701331	
663	ICE LINED REFRIGERATOR	HAIER HBC 70	STARTING RELAY	STARTING RELAY	70701331	
664	ICE LINED REFRIGERATOR	HAIER HBC 70	COMPRESSOR	COMPRESSOR	70701331	
665	ICE LINED REFRIGERATOR	HAIER HBC 70	HOT SHORTEN TUBE	HOT SHORTEN TUBE	79020006	








666	ICE LINED REFRIGERATOR	HAIER HBC 70	FILTER DRIER	FILTER DRIER	74180002	
667	ICE LINED REFRIGERATOR	HAIER HBC 70	ENGINE ROOM COVER	ENGINE ROOM COVER	71210004	
668	ICE LINED REFRIGERATOR	HAIER HBC 70	WASHER	WASHER	72130038	
669	ICE LINED REFRIGERATOR	HAIER HBC 70	SCREW	SCREW	77010036	
670	ICE LINED REFRIGERATOR	HAIER HBC 70	HINGE	HINGES	78090012	
671	ICE LINED REFRIGERATOR	HAIER HBC 70	SCREW	SCREW	77050002	
672	ICE LINED REFRIGERATOR	HAIER HBC 70	BOTTOM HINGE COVER	BOTTOM HINGE COVER	72040011	

673	ICE LINED REFRIGERATOR	HAIER HBC 70	TOP HINGE COVER	TOP HINGE COVER	72040003		
674	ICE LINED REFRIGERATOR	HAIER HBC 70	COMPARTMENT GRILL	COMPARTMENT GRILL	72220007		
675	ICE LINED REFRIGERATOR	HAIER HBC 70	SCREW	SCREW	77050058		
676	DEEP FREEZER	HAIER HBD 116 / HBD 286	GRILL	CABIN GRILL FOR HBD (BLUE)	70202325		
677	DEEP FREEZER	HAIER HBD 116 / HBD 286	SCRAPER	ICE SCRAPER	70202413		
678	DEEP FREEZER	HAIER HBD 116 / HBD 286	FOOT BASE	FOOT BASES	70202664		
679	DEEP FREEZER	HAIER HBD 116 / HBD 286	CONTROL PANEL	CONTROL PANEL FOR HBD	70202720		


680	DEEP FREEZER	HAIER HBD 116 / HBD 286	CORD	POWER CORD FOR HBD	70402375	
681	DEEP FREEZER	HAIER HBD 116	COMPRESSOR	COMPRESSOR NL6.1FT	70701331	
682	DEEP FREEZER	HAIER HBD 286	COMPRESSOR	COMPRESSOR NL7.1FT	70701332	
683	DEEP FREEZER	HAIER HBD 116 / HBD 286	CONDENSER	LITTLE CONDENSER	70701369	
684	DEEP FREEZER	HAIER HBD 286	TUBE	SUCTION TUBE FOR HBD-286	70702007	
685	DEEP FREEZER	HAIER HBD 116	TUBE	SUCTION TUBE FOR HBD-116	70702009	
686	DEEP FREEZER	HAIER HBD 116 / HBD 286	HANDLE	DOOR HANDLE	70804793	

687	DEEP FREEZER	HAIER HBD 116 / HBD 286	BASKET	BASKET FOR HBD	71090001		
688	DEEP FREEZER	HAIER HBD 116 / HBD 286	LOCK	LOCK NOSE	71150025		
689	DEEP FREEZER	HAIER HBD 116 / HBD 286	COVER	COVER FOR CABIN	71210004		
690	DEEP FREEZER	HAIER HBD 116 / HBD 286	THERMOMETER	MERCURY THERMOMETER	71400789		
691	DEEP FREEZER	HAIER HBD 116 / HBD 286	COVER	COVER FOR UPPER HINGE	72040003		
692	DEEP FREEZER	HAIER HBD 116 / HBD 286	COVER	COVER FOR LOWER HINGE	72040011		
693	DEEP FREEZER	HAIER HBD 116 / HBD 286	THERMOSTAT KNOB	KNOB OF THERMOSTATE FOR	72040122		

694	DEEP FREEZER	HAIER HBD 116 / HBD 286	DISPLAY	TEMPERATURE DISPLAYER FOR	74090718		
695	DEEP FREEZER	HAIER HBD 116 / HBD 286	THERMOSTAT	THERMOSTATE FOR HBD	74090880		
696	DEEP FREEZER	HAIER HBD 116 / HBD 286	VOLTAGE STABILISER	VOLTAGE STABILIZER	74091513		
697	DEEP FREEZER	HAIER HBD 116 / HBD 286	DRIER	DRIER	0074180002A		
698	DEEP FREEZER	HAIER HBD 116 / HBD 286	FAN MOTOR	FAN	75030020		
699	DEEP FREEZER	HAIER HBD 116 / HBD 286	SWITCH	POWER SWITCH	75050003		
700	DEEP FREEZER	HAIER HBD 286	HINGE	HINGE	78090002		





701	DEEP FREEZER	HAIER HBD 116	HINGE	HINGE	78090012		
702	DEEP FREEZER	HAIER HBD 286	STARTING DEVICE	STARTING RELAY FOR COMPRESSOR NL7FT	74091512		
703	DEEP FREEZER	HAIER HBD 116	CAPACITOR	STARTING RELAY FOR COMPRESSOR NL7FT/6.1 FT	74091511		
704	DEEP FREEZER	HAIER HBD 116	STARTING DEVICE	STARTING RELAY FOR COMPRESSOR NL6.1FT	74091510		
705	WALK - IN - COOLER	(FOS) COOLING UNIT	FAN BLADE	FAN BLADE "10" FOR EVAPORATOR FAN	15871029	0487	
706	WALK - IN - COOLER	(FOS) COLD ROOM	HANDLE	DOOR HANDLE, INNER RELEASE, 2838	15230216-6	0488	
707	WALK - IN - COOLER	(FOS) COLD ROOM	THERMOMETER	RECORDING THERMOMETER MDL EPI/RFBD (E6/39	(REPL FOR 0154)0154	0492	


708	WALK - IN - COOLER	(FOS) GENR ENGINE	FILTER	OIL FILTER ELEMENT DM 188 PUROLATOR	L17603.FC60 3	0503	
709	WALK - IN - COOLER	(FOS) GENR ENGINE	FILTER	OIL FILTER ELEMENT DM 188 BOSCH	451103141	0504	
710	DEEP FREEZER	VESTFROST MF 304	COMPRESSOR	DANFOSS COMPRESSOR 10G COMPLETE		0801	
711	ICE LINED REFRIGERATOR	VESTFROST MK 304	COMPRESSOR	DANFOSS COMPRESSOR FR 8.5 G COMPLETE		0802	
712	DEEP FREEZER	VESTFROST MF 144	COMPRESSOR	DANFOSS COMPRESSOR FR6G COMPLETE		0803	
713	ICE LINED REFRIGERATOR	VESTFROST MK 144	COMPRESSOR	DANFOSS COMPRESSOR TL5G HST		0804	
714	ILR / FREEZER	VESTFROST MF 304/ MF144	STARTING DEVICE	STARTING DEVICE FR 10 G FR6G COMPRESSOR		0805	

715	ILR / FREEZER	VESTFROST MK 304	STARTING DEVICE	STARTING DEVICE FOR FR 8.5 COMPRESSOR		0806	
716	ILR / FREEZER	VESTFROST MK 144	STARTING DEVICE	STARTING DEVICE FOR TL5G HST COMPRESSOR		0807	
717	Deep Freezer	VESTFROST FREEZER	THERMOSTAT	THERMOSTAT (FREEZER)		0808	
718	ICE LINED REFRIGERATOR	VESTFROST ILR	THERMOSTAT	THERMOSTAT(ILR)		0809	
719	ICE LINED REFRIGERATOR	VESTFROST ILR	THERMOSTAT	THERMOSTAT FOR ICE PACK		0810	
720	ILR / FREEZER	VESTFROST ILR/FREEZER	SUSPENTION	THERMOSTAT SUSPENTION		0811	
721	ILR / FREEZER	VESTFROST ILR/FREEZER	THERMOSTAT KNOB	THERMOSTAT KNOB		0812	




722	ILR / FREEZER	VESTFROST ILR/FREEZER	THERMOMETER	THERMOMETER (DIGITAL)		0813	
723	ILR / FREEZER	VESTFROST ILR/FREEZER	THERMOMETER	THERMOMETER (STEM)		0814	
724	ILR / FREEZER	VESTFROST ILR/FREEZER	INDICATOR LAMP	PILOT LAMP RED/GREEN		0815	
725	ILR / FREEZER	VESTFROST FREEZER	SWITCH	PILOT LAMP FAST FREEZE SWITCH		0816	
726	ILR / FREEZER	VESTFROST ILR/FREEZER	DRIER	FILTER DRIER 20 G		0821	
727	ILR / FREEZER	VESTFROST - MF304 / MK304 /MF144	FAN MOTOR	FAN COMPLETE FOR COMPRESSOR		0825	
728	ICE LINED REFRIGERATOR	VESTFROST MK 304	CAPACITOR	STARTING CONDENSER FOR ILR - 304		0826	








729	ICE LINED REFRIGERATOR	VESTFROST MK 144	CAPACITOR	STARTING CONDENSER FOR ILR - 144		0827	
730	ILR / FREEZER	ELECTROLUX TCW 1990	COMPRESSOR	COMPRESSOR FR8.5G 220 VOLTS FOR TCW - 1990 CFC FREE		0828	
731	ILR / FREEZER	ELECTROLUX TCW 1990	STARTING DEVICE	STARTING DEVICE TCW 1990		0829	
732	ILR / FREEZER	ELECTROLUX TCW 1990	THERMOSTAT	THERMOSTAT		0832	
733	ILR / FREEZER	ELECTROLUX TCW 1990	THERMOSTAT	THERMOSTAT EXT		0833	
734	ILR / FREEZER	ELECTROLUX TCW 1990	CAPACITOR	CAPACITOR		0835	
735	ILR / FREEZER	ELECTROLUX TCW 1990	FAN MOTOR	FAN COMPLETE		0836	

736	ILR / FREEZER	ELECTROLUX TCW 1990	FAN MOTOR	FAN INT CPL		0837	
737	ILR / FREEZER	ELECTROLUX TCW 1990	DRIER	DRIER		0838	
738	WALK - IN - COOLER	HURRE MPP13 A	COMPRESSOR	COMPRESSOR TECHUMSEH UROPA FOR COOLING UNIT	M1	0839	
739	WALK - IN - COOLER	HURRE MPP13 A	COMPRESSOR	COMPRESSOR FOR 404/507 MANEURY RECIPROCATING	M1	0840	
740	WALK - IN - COOLER	HURRE MPP13 A	FAN MOTOR	CONDENSER FAN - FMV-LAMEL 230 V 0.85 LAMP 1500 RPM	M2	0841	
741	WALK - IN - COOLER	HURRE MPP13 A	FAN MOTOR	EVAPORATOR FAN - FMV - LAMEL MADE IN FRANCE	M3	0842	
742	WALK - IN - COOLER	HURRE MPP13 A	CONTACTOR	COMPRESSOR CONTACTOR ABB	KM1	0843	


743	WALK - IN - COOLER	HUURRE MPP13 A	HEATER	DRAIN TUBE HEATER	EH 41 & 42	0844	
744	WALK - IN - COOLER	HUURRE MPP13 A	OVER LOAD PROTECTOR	COMPRESSOR THERMAL PROTECTOR	ST 1	0845	
745	WALK - IN - COOLER	HUURRE MPP13 A	CONTACTOR	CONTACTOR - SPRECHER + SCHI	K 1	0846	
746	WALK - IN - COOLER	HUURRE MPP13 A	CONTACTOR	CONTACTOR - SPRECHER + SCHI 25 AMP 230 V	K 2	0847	
747	WALK - IN - COOLER	HUURRE MPP13 A	CIRCUIT BREAKER	CIRCUIT BREAKER - LEGRAND	F11	0849	
748	WALK - IN - COOLER	HUURRE MPP13 A	CIRCUIT BREAKER	CIRCUIT BREAKER - LEGRAND	F10 & 20 and F30 & 40	0850	
749	WALK - IN - FREEZER	HUURRE MPN 36 A	HEATER	FLOW HEATER	EH 3	0851	

750	WALK - IN - FREEZER	HUURRE MPN 36 A	HEATER	DEFROST HEATER	EH 20 & 21	0852	
751	WALK - IN - FREEZER	HUURRE MPN 36 A	HEATER	DRAIN TUBE HEATER	EH 40 & 41	0853	
752	WALK - IN - FREEZER	HUURRE MPN 36 A	CONTACTOR	COMPRESSOR CONTACTOR ABB 09-30-10	KM 1	0854	
753	WALK - IN - FREEZER	HUURRE MPN 36 A	FAN MOTOR	CONDENSER FAN FMV TYPE JA 350-VD-41 230 V.T 2 AMP 230WATT	M 21 & 22	0855	
754	WALK - IN - FREEZER	HUURRE MPN 36 A	FAN MOTOR	EVAPORATOR FAN FMV TYPE A40-4PL 25 230 V.T A 205 WATT 1500 RPM	M 31 & 32	0856	
755	WALK - IN - FREEZER	HUURRE MPN 36 A	DIGITAL TEMPERATURE CONTROLLER	ELECTRICAL REGULATOR (MASTER LOG)	MLOG	0857	
756	WALK - IN - FREEZER	HUURRE MPN 36 A	CIRCUIT BREAKER	CIRCUIT BREAKER	QM1	0858	

757	WALK - IN - FREEZER	HUURRE MPN 36 A	SENSOR	S 1 AMBIENT SENSOR	RT 1	0859	
758	WALK - IN - FREEZER	HUURRE MPN 36 A	SENSOR	S 2 DEFROST SENSOR	RT 2	0860	
759	WALK - IN - FREEZER	HUURRE MPN 36 A	SWITCH	HP PRESSURE SWITCH	SP 1	0861	
760	WALK - IN - FREEZER	HUURRE MPN 36 A	PANEL	GENERATOR - PANEL POWER CONTROL UNIT 400V 16A 10KVA 10KW	CEIE 60439-1	0862	
761	WALK - IN - FREEZER	HUURRE MPN 36 A	PANEL	GENERATOR - PANEL POWER CONTROL UNIT 400V 16A 10KVA 10KW		0862	
762	WALK - IN - FREEZER	HUURRE MPN 36 A	CONTACTOR	CONTACTOR (NET WORK) SPRECHER + SCHI	K 1	0863	
763	WALK - IN - FREEZER	HUURRE MPN 36 A	CONTACTOR	CONTACTOR (GENERATOR) 25 A 230 V	K 2	0864	


764	WALK - IN - FREEZER	HUURRE MPN 36 A	TIMER	DEFROST TIMER	EWTS-72	0865	
765	WALK - IN - FREEZER	HUURRE MPN 36 A	VALVE	SOLINOIDE VALVE	O18Z-625	0866	
766	WALK - IN - FREEZER	HUURRE MPN 36 A	TEMPERATURE RECORDER	TEMPERATURE RECORDER		0867	
767	WALK - IN - FREEZER	HUURRE MPN 36 A	TEMPERATURE SUPERVISOR	TEMPERATURE SUPERVISOR		0868	
768	WALK - IN - FREEZER	HUURRE MPN 36 A	CHART	TEMPERATURE RECORDER CHART		0869	
769	WALK - IN - FREEZER	HUURRE MPN 36 A	ALARM SYSTEM	ALARM UNIT		0870	
770	WALK - IN - FREEZER	HUURRE MPN 36 A	SOLENOID	STOP SOLENOID 12 V DC	9LD-625-2	0871	





771	WALK - IN - FREEZER	HURRE MPN 36 A	SOLENOID	START SOLENOID 12 V DC	9LD-625-2	0872	
772	WALK - IN - FREEZER	HURRE MPN 36 A	FILTER	OIL FILTER	9LD-625-2	0873	
773	WALK - IN - FREEZER	HURRE MPN 36 A	FILTER	FUEL FILTER	9LD-625-2	0874	
774	WALK - IN - FREEZER	HURRE MPN 36 A	BENDIX	STARTER BENDIX	9LD-625-2	0875	
775	WALK - IN - FREEZER	HURRE MPN 36 A	SWITCH	SOLENOID SWITCH SPRING LOADED 12 V DC	F-913001	0876	
776	SOLAR REFRIGERATOR	VC 150/VC 65	SOLAR PANEL	SOLAR MODULES-KYOCERA/KD145GH-4YU/EUROPE-145 WATT	KD145GH-4YU/00010	0877	
777	SOLAR REFRIGERATOR	VC 150/VC 65	BATTERY	SEALED GEL BATTERY-BAE/6V 4PVV280/GERMANY	6V 4PVV280 /00020	0878	

778	SOLAR REFRIGERATOR	VC 150/VC 65	HINGE	HINGES (KNUCLE)	/00030	0879	
779	SOLAR REFRIGERATOR	VC 150/VC 65	LOCK	DOOR LOCK	/00040	0880	
780	SOLAR REFRIGERATOR	VC 150/VC 65	CONTROLLER	COMP.CONTROLLER ELECTRONIC UNIT, SECOP /101N0210/CHINA(For BD35 F COMPRESSOR)	FRCC101N02 010/00060	0881	
781	SOLAR REFRIGERATOR	VC 150/VC 65	FUSE	FUSES=15 A	APFUSE15 /563-750/00070	0882	
782	SOLAR REFRIGERATOR	VC 150/VC 65	CONTROLLER	TEMPERATURE CONTROLLER WITH PROBES_1A-1A/7-30 Vdc lae/AT-5BQ8L-3PS/ITALY	FRTEMPSOC/ 00080 WITH FR PROBE1.5 & FR PROBE 2.5	0883	
783	SOLAR REFRIGERATOR	VC 150/VC 65	CONTROLLER	CHARGE CONTROLLER-12/24 VDC, 45ATarom/4545/BULGARIA	CCDULAST AROM4545/ 748.067/0009 0	0884	
784	SOLAR REFRIGERATOR	VC 150/VC 65	COMPRESSOR	COMPRESSOR (WITH ELECT. ONTROLLER)-12/24 VDC, DANFOSS/BD35F/ CHINA	101Z 0200/	0885	

785	WALK-IN COOLER/FREEZER (ZHENDRE)	FREEZING & COOLING UNIT (N36A/ P25AD/ N26)..Make EUROMON	FAN MOTOR	CONDENSER/ EVAP. FAN MOTOR-1 Ph,230V, 50Hz, 177W,1300 RPM. ZIEHL-ABEGG/France	VE0024900/17353	0886	
786	WALK-IN COOLER/FREEZER (ZHENDRE)	FREEZING & COOLING UNIT (N36A/P25AD/ N26)..Make EUROMON	CONTACTOR	CONTACTOR,25A,230V,50 Hz,11KW/400V.....SCHNEIDER/ELECTRIC/ LC1D25P7/ FRANCE	034995/1391	0887	
787	WALK-IN COOLER/FREEZER (ZHENDRE)	FREEZING & COOLING UNIT (N36A/P25AD/ N26)..Make EUROMON	CONTROLLER	DIGITAL TEMPERATURE CONTROLLER WITH SET OF SENSORS, 230V A.C./20 Amps/4VA, DIXELL/XW60L	WH7RBNC5 AC/17347	0888	
788	WALK-IN COOLER/FREEZER (ZHENDRE)	COOLING UNIT-P25AD	COMPRESSOR	COMPRESSOR,380-400V,3PH.,50Hz,7.5A.....DANFOSS/ MTZ28JE4AVE/ FRANCE	MTZ28-VM/17351	0889	
789	WALK-IN COOLER/FREEZER (ZHENDRE)	FREEZING UNIT-N36A	COMPRESSOR	COMPRESSOR,380-400V,3PH.,50Hz,10.1A.....DANFOSS/ NTZ096A4LR1A/France	120F0010/20354	0890	
790	WALK-IN COOLER (HAIER)	COOLING UNIT	FAN MOTOR	CONDENSER FAN MOTOR.A.C.220V/50Hz/ 0.85A/180W/2300 R.P.M.... YWF 2E-300S-E5L		0891	
791	WALK-IN COOLER (HAIER)	COOLING UNIT	CONTACTOR	CONTACTOR,25A,230V,50 Hz, 11KW/380V....SCHNEIDER/ELECTRIC/ LC1D25M7C/ FRANCE	/02510 M700	0892	

792	WALK-IN COOLER (HAIER)	COOLING UNIT	CONTROLLER	DIGITAL TEMPERATURE CONTROLLER WITH TEMP. SENSORS...230 V A.C./ 20A/3.5VA....DIXELL/XR06 CX	LI0GBXB500 /	0893	
793	WALK-IN COOLER (HAIER)	COOLING UNIT	FAN MOTOR	EVAPORATOR FAN MOTOR.A.C.220V/50Hz/ 0.85A/180W/2300 R.P.M....YWF 2E-300S-E5L		0894	
794	WALK-IN COOLER (HAIER)	COOLING UNIT	COMPRESSOR	COMPRESSOR.400V,3PH., 50Hz,3.7A....TECUMSEH/T FH2511Z/France	/6547230100	0895	
795	WALK-IN FREEZER (HAIER)	FREEZING UNIT	COMPRESSOR	COMPRESSOR.400V,3PH., 50Hz,3.7A....TECUMSEH/T FH4524Z/France		0896	
796	WALK-IN COOLER/FREEZER (HAIER)		PANEL	COLD ROOM PANEL		0897	
797	WALK-IN COOLER (PORKKA)	COOLING UNIT	COMPRESSOR	COMPRESSOR..380-400V,3PH.,50Hz,6A....DAN FOSS/ MTZ22JC4AVE/ FRANCE		0898	
798	WALK-IN-FREEZER (PORKKA)	FREEZING UNIT	COMPRESSOR	COMPRESSOR..380-400V,3PH.,50Hz,8.4A...DAN FOSS/ NTZ068A4LR1A/ FRANCE		0899	

799	WALK-IN FREEZER (PORKKA)	FREEZING UNIT	CONTACTOR	CONTACTOR, I - 60 Amps,50/60Hz/Uimp-6KV.....SCHNEIDER/ELECTRIC/ LC1DT60AP7/ FRANCE		0900	
800	WALK-IN-COOLER (BLUE STAR)	COOLING UNIT	TEMPERATURE RECORDER	SUBZERO			
801	WALK-IN-COOLER (BLUE STAR)	COOLING UNIT	TEMPERATURE CONTROLLER	BLUE STAR			
802	WALK-IN-COOLER (BLUE STAR)	CONDENSING UNIT	SOLINOID VALVE	DANFOSS			
803	WALK-IN-COOLER (BLUE STAR)	CONDENSING UNIT	COMPRESSOR	DANFOSS MANUROP			
804	WALK-IN-COOLER (BLUE STAR)	CONDENSING UNIT	CONDENSOR FAN	CONDENSOR FAN			
805	WALK-IN-COOLER (BLUE STAR)	CONDENSING UNIT	FILTER DRIER	FILTER DRIER, DANFOSS			

806	WALK-IN-COOLER (BLUE STAR)	CONDENSING UNIT	LIQUID INDICATOR	LIQUID INDICATOR			
807	WALK-IN-COOLER (BLUE STAR)	CONDENSING UNIT	LIQUID RECEIVER	LIQUID RECEIVER			
808	WALK-IN-COOLER (BLUE STAR)	CONDENSING UNIT	OIL SEPERATOR	OIL SEPERATOR			
809	WALK-IN-COOLER (BLUE STAR)	CONDENSING UNIT	HP-LP SWITCH	HP-LP-SWITCH DANFOSS			
810	WALK-IN-COOLER (BLUE STAR)	CONDENSING UNIT	PRESSURE SWITCH	PRESSURE SWITCH DANFOSS			